



***Revised Former Fire Stations Groundwater  
Characterization Work Plan  
Portland International Airport  
Portland, Oregon  
ECSI No. 3324***

**Prepared for:  
Port of Portland**

**November 19, 2024  
32-24009923**



***Revised Former Fire Stations Groundwater  
Characterization Work Plan  
Portland International Airport  
Portland, Oregon  
ECSI No. 3324***


Prepared for:  
Port of Portland

November 19, 2024  
32-24009923

A handwritten signature in blue ink that reads 'Carmen Owens'.

---

Carmen Owens, P.E.  
Associate Engineer



**EXPIRES: DEC. 31, 2025**

---

Herb Clough, P.E.  
Principal Engineer

---

## ***Table of Contents***

1.0 INTRODUCTION .....	1
1.1 Purpose .....	1
1.2 Site Description .....	1
1.3 Overview of Hydrogeology .....	1
1.4 PFAS in Groundwater.....	2
2.0 MONITORING WELL NETWORK.....	2
3.0 SCOPE OF WORK .....	3
4.0 INVESTIGATION ACTIVITIES.....	4
4.1 Preparatory Activities.....	4
4.2 Field Activities.....	5
5.0 ANALYTICAL PROGRAM .....	7
6.0 REPORTING.....	7

## **Tables**

1	Groundwater Concentrations
2	Former Fire Stations Site Characterization Plan

## **Figures**

1	Site Location Map
2	Site Vicinity Plan
3	Shallow (OD) Groundwater Elevations Contour Map (May 2023)
4	Shallow (OD) Groundwater Elevations Contour Map (November 2023)
5	Deep (CRSA) Groundwater Elevations Contour Map (May 2023)
6	PFOS and PFOA in Shallow (OD) Groundwater
7	Former Fire Stations Proposed Well and Boring Locations

## **Appendices**

A	Monitoring Well Logs
B	Sampling and Analysis Plan
C	Health and Safety Plan

---

## **1.0 Introduction**

This Work Plan for site characterization provides the Oregon Department of Environmental Quality (DEQ) with a scope of work to conduct groundwater sampling in the vicinity of the two Former Fire Stations (Figures 1 and 2) identified as an area of interest (AOI) in the *Preliminary Assessment: Aqueous Film-Forming Foam Use* (Preliminary Assessment; Apex, 2017). Work at the Site is being conducted with oversight from the DEQ in accordance with the Voluntary Cleanup Agreement between the DEQ and the Port of Portland (Port) for ECSI No. 3324, dated February 8, 2017.

### **1.1 Purpose**

The purpose of this Work Plan is to describe the scope of work to be completed to define the nature and extent of per- and polyfluoroalkyl substances (PFAS) in groundwater near the Former Fire Stations at the Portland International Airport (PDX). The Former Fire Stations were identified as an AOI because of potential application and use of extinguishing agents containing PFAS.

### **1.2 Site Description**

The Former Fire Stations are located in the northwest portion of PDX (Figure 2). The first fire station was in operation from 1960 to 1972. The second station was located southwest of the original and was in operation from 1972 to 1997. Historical activities included firetruck and equipment storage and associated training (e.g., operation of pumps, loading of concentrate) and equipment maintenance.

### **1.3 Overview of Hydrogeology**

Hydrogeological units present beneath PDX include the overbank deposit (OD) and the Columbia River sand aquifer (CRSA). The OD consists of fine-grained sediments deposited in floodplains adjacent to river channels. In this environment, natural levees are present along the riverbank immediately adjacent to the channel and are thickest at the channel bank and thin toward the floodplain. The OD aquifer is present throughout PDX and is typically between 50 and 60 feet thick, though the overall range is from 20 to 110 feet. Based on the well log for monitoring well TCORE-3, the OD could be as much as 110 feet thick in the vicinity of the Former Fire Stations. Based on results from exploratory borings, the OD consists of soft to stiff, gray (upper portions may be brown) layers of silty clay, silt, silty sand, and sandy silt, with occasional organic or wood debris. Individual layers vary from 5 to 20 feet in thickness. Sandy layers are more likely to be present in the lower portion of this unit, especially where it transitions to the CRSA (if present). Dredge sand fill placed during airport development is present at the ground surface throughout much of PDX.

Groundwater flow in the OD has variable direction and hydraulic gradient across the Site, with the dominant groundwater flow direction in the nearby Fire Training Facilities to the north-northwest (towards the Columbia River). Groundwater monitoring events conducted in May and November 2023 included one well from the



---

Former Fire Station area (MW-12-L58397). Combining data from MW-12-L58397 with data from the Fire Training Facilities well network shows a gradient to the north-northwest (Figures 3 and 4). It is expected that additional monitoring at the Former Fire Stations will confirm the dominant groundwater flow direction of north-northwest.

The CRSA fills a former channel of the ancestral Columbia River, just south of the present-day Columbia River channel. This paleochannel segment has a depth of more than 300 feet, eroded within older sedimentary units such as the Troutdale Gravel Aquifer and Confining Unit 1. The approximate southern extent of this channel generally corresponds to the southern limit of PDX. Where present, the top of the CRSA ranges from 20 to 110 feet below ground surface (bgs). The CRSA is comprised of medium-dense to dense, gray, gray-brown, or black fine- to medium-grained, quartz-rich basaltic sand.

Groundwater flow direction in the CRSA is typically to the north-northeast; however, flow has been observed to the west-southwest when the Columbia River is at flood stage. The groundwater gradient in the deep CRSA aquifer during May 2023 monitoring events is shown on Figure 5.

#### **1.4 PFAS in Groundwater**

To date, groundwater reconnaissance monitoring in several existing monitoring wells has verified the presence of PFAS in the OD in the vicinity of the Former Fire Stations. Detected concentrations of PFAS in this vicinity are greater than PFAS concentrations in the nearest Fire Training Facilities monitoring wells, suggesting the potential for source area(s) associated with the Former Fire Stations. Data from groundwater sampling in the vicinity of the Former Fire Stations is presented in Table 1 and on Figure 6. PFAS have not been detected in CRSA wells sampled in the vicinity of the Fire Training Facilities.

## **2.0 Monitoring Well Network**

The Port will use newly installed wells in conjunction with existing wells to create a well network to fully delineate PFAS in groundwater near the Former Fire Stations. The proposed monitoring program is shown on Table 2 with existing and proposed well locations shown on Figure 7. Details of installation and sampling are provided in the sections below.

In the OD, monitoring wells MW-11-L58501 and MW-12-L58397 within the Former Fire Stations area show elevated concentrations of PFAS. To delineate this groundwater to the south, existing monitoring wells MW-6, MW-8, and MW-14 will be sampled. To delineate groundwater to the northeast, monitoring well MW-101 will be installed. MW-102 will be installed to delineate to the northwest. Existing monitoring well MW-1 will be sampled to delineate concentrations to the east. Well installations in the areas directly north and west of the Former Fire Stations are limited by the terminal building, runways, and taxiways.

---

Concentrations in Fire Training Facilities wells to the north and west are well established and can be used in conjunction with the proposed well network if needed to fully delineate PFAS around the Former Fire Stations.

In the CRSA, three wells will be used to assess PFAS concentrations. Existing well TCORE-3 is located north of the Former Fire Stations Area. Two wells will be installed in the CRSA to the northwest and west of the Former Fire Stations area (DW-101 and DW-102). This will confirm that PFAS are not migrating from the Former Fire Stations to the Columbia River via the CRSA.

### **3.0 Scope of Work**

**Monitoring Well Installation.** Four monitoring wells will be installed. These wells will be used in conjunction with existing wells to delineate groundwater near the Former Fire Stations. Two wells will be installed in the OD and two in the CRSA. Proposed locations are shown on Figure 7.

**Temporary Borings.** Four temporary borings will be installed near the south runway. Groundwater will be collected from the borings to delineate PFAS concentrations near previous boring B-4. Proposed locations are shown on Figure 7.

**Soil Sampling.** Soil samples will be collected and analyzed to assess soil handling options for future development projects. Soil will be composited from the saturated and unsaturated zones separately at three areas of the Site: north of the Former Fire Stations, near the south runway, and west of the Former Fire Stations. The unsaturated zone is defined as soil that is above the seasonally high groundwater level. The saturated zone is soil below this level.

**Groundwater Monitoring.** Groundwater samples will be collected from both existing and newly installed wells.

Eight OD monitoring wells will be gauged and sampled. Six of these are existing wells installed for prior investigations of jet fuel releases in the vicinity of Concourse C. The two new OD wells are proposed as shown on Figure 7 (well installation methods are discussed below).

Three CRSA monitoring wells will be gauged and sampled. One is an existing well installed for the Terminal Core Redevelopment (TCORE) project. The two new CRSA wells are proposed as shown on Figure 7. The proposed locations of the wells may be adjusted to maintain safe airfield operations.

A table summarizing the groundwater monitoring program is provided on Table 2. Well logs for the existing monitoring wells proposed for sampling at the Former Fire Stations area are provided in Appendix A.

---

## **4.0 Investigation Activities**

The scope of work includes monitoring well installation, temporary borings, soil sampling, and groundwater monitoring. Detailed field and sampling procedures are described in the Sampling and Analysis Plan (SAP) provided in Appendix B.

### **4.1 Preparatory Activities**

**Property Access.** Apex will provide notification to Port personnel and Port Operations (OPS) to coordinate access to the Site at PDX. The notification will be submitted to OPS one week in advance and include the following:

- Port project manager contact information;
- Apex project manager and PDX field staff contact information;
- Summary of field work;
- Site plan showing work locations;
- Ingress and egress locations for Apex and subcontractors;
- List of subcontractors; and
- Work schedule.

Depending on the location of work, either a Port escort will be provided or badged Apex employees will escort un-badged subcontractor(s). Airside OPS will be notified of the contractors' arrival and departure.

**Underground Utility Location.** Apex's project manager or designee will mobilize to the Site to mark out the proposed sampling locations with marking paint in order to enable identification of nearby underground utilities by Oregon Utilities Notification Center (Oregon 811). Because Oregon 811 does not mark out underground utilities on private property and because the drilling activities will be performed inside the boundaries of the Site, Port personnel will conduct an underground utility locate to mark out underground utilities located within the proximity of each proposed sampling location prior to performing the subsurface work.

If any underground utilities are identified within 5 feet of a proposed sampling location, Apex will adjust the proposed sampling location before drilling commences. Apex will also adjust the proposed drilling location to provide a safety buffer for buildings, heavy traffic areas, overhead utilities, and similar Site features so that sampling can be performed safely and with minimal disruption to existing businesses.

As an additional safety measure, all borings will be hand-cleared using a hand auger, air-knife, or post hole digger to approximately 5 feet bgs.

---

**Site Health and Safety Plan.** A Site-specific health and safety plan (HASP) has been prepared for the proposed activities (Appendix C). The HASP was prepared in general accordance with the Occupational Safety and Health Administration (OSHA) and the Oregon Administrative Rules (OAR). A copy of the HASP will be maintained on-site during the field activities.

## 4.2 Field Activities

**Monitoring Well Installation.** Four groundwater monitoring wells will be installed in the vicinity of the Former Fire Stations at the locations shown on Figure 7. Two wells (MW-101 and MW-102) will be installed in the OD to an approximate depth of 20 feet bgs based on recent and historical groundwater levels. Two wells (DW-101 and DW-102) will be installed in the upper CRSA to an approximate depth of 80 to 100 feet bgs based on the estimated depth of 70 to 90 feet to the OD/CRSA contact. The final depth of each CRSA well will be determined based on lithologic conditions with the top of the screen approximately 10 feet below the OD/CRSA contact.

The OD monitoring wells will be installed using direct push drilling methods. The CRSA monitoring wells will be installed using sonic drilling methods. They will be constructed of 2-inch diameter, Schedule 40 PVC casing with 10 feet of Schedule 40 PVC screen with 0.010-inch slots. A clean 20/30 silica sand pack will be placed between the boring wall and the PVC screen and riser from the bottom of the well to approximately 1 to 2 feet above the screened interval. A bentonite seal will be placed above the sand pack to within approximately 1 to 2 feet of the ground surface. For wells installed with sonic drilling methods and dual casing will be used to prevent cross contamination. Additionally, the bentonite seal will be placed through a side-discharge Tremie pipe to ensure positive placement without bridging or wash-out of previously placed annular materials. The seal will displace standing fluid in the zone and set up without being diluted by formation water.

The surface will be completed with a traffic-rated flush-mounted concrete well pad and monument. A watertight locking cap and lock will secure the wellhead, and tamper-resistant bolts will secure the monument cover.

Lithologic descriptions will be prepared for the full length of the borings. Soil cores will be screened for volatile organic compounds using a photoionization detector (PID). Lithologic descriptions will be prepared in general accordance with ASTM 2487/2488.

Additional monitoring well installation procedures are detailed in the SAP (Appendix B).

**Monitoring Well Development.** At least twenty-four hours after installation and prior to sampling, the newly installed monitoring wells will be developed to ensure connection with the aquifer. The well development will be conducted using a submersible pump. Development will be considered complete when a minimum of five well bore volumes have been removed from the well and the water is chemically stable and free of sediment. Water produced from the well is considered chemically stable when field parameters (pH, temperature,

---

specific conductance, oxidation-reduction potential, and dissolved oxygen) remain within five percent of the previous measurement for at least three successive borehole volumes. Water produced during well development activities will be containerized and handled as described in the investigation-derived waste (IDW) section below.

**Temporary Borings.** Four borings will be installed using direct push drilling methods. The borings will be completed to a depth that allows for the collection of a groundwater sample. Based on previous borings conducted in the same area, the depth to groundwater is expected to be between 3 and 8 feet bgs. To allow for the collection of the groundwater, the borings are expected to be extended approximately 5 feet into the water table (i.e., to depths of 8 to 13 feet bgs). Groundwater samples will be collected from each boring using dedicated tubing and a peristaltic pump. Soil lithology and conditions will be logged in general accordance with ASTM 2487/2488. Soil cores will be field-screened at approximately 2-foot intervals using a PID and sheen testing. The location of each direct push boring will be recorded using a high-accuracy handheld global positioning system (GPS) unit.

Each direct push boring will be abandoned in accordance with the Oregon Water Resources Department regulations and procedures. The abandonment procedure typically consists of backfilling the boring with granular bentonite and hydrating with water.

**Soil Sampling.** Samples will be collected from distinct areas of the Site to assist in disposal during future work. The three distinct areas are north, south, and west of the Former Fire Stations. Soil from well MW-101 will be used to assess the north. Soil from the four temporary borings (near previous boring B-4 on Figure 6) will be composited together to assess the south. Soil from MW-102, DW-101, and DW-102 will be composited to assess the area to the west. A sample will be collected from both the saturated and unsaturated zone at each area. This will be a total of six soil samples for analysis. Discrete samples will be collected from each location and held for possible follow up analysis.

Based on previously installed wells and borings, the unsaturated zone is expected to be from the ground surface to 8 feet bgs north of the Former Fire Stations, 3 feet bgs near boring B-4, and 4 feet bgs to the west of the Former Fire Stations.

Additional soil sampling procedures, sample handling, and quality assurance/quality control (QA/QC) procedures are detailed in the SAP (Appendix B).

**Groundwater Levels.** Groundwater levels will be measured from monitoring wells prior to collecting groundwater samples. The wells will be opened to allow water levels to equilibrate before the measurements are recorded. The depth to groundwater, free product, and/or sheen will be measured in each well to the nearest 0.01 foot using an electronic oil-water interface probe.

---

**Groundwater Monitoring.** Wells will be sampled using low-flow methods with a peristaltic pump and dedicated PFAS-free tubing. Prior to the collection of groundwater samples, pH, conductivity, temperature, dissolved oxygen, and oxidation-reduction potential will be measured using a water parameter meter with flow cell connected to the discharge tubing of the sample pump for samples collected from the monitoring wells. Turbidity of the water will be monitored visually, and the color and clarity of the water will be recorded on the sampling data sheet. Purging will be considered complete when the water quality parameters have stabilized to within 10 percent and the water is visually clear for three consecutive three-minute intervals.

Additional groundwater sampling procedures, sample handling, and QA/QC procedures are detailed in the SAP (Appendix B).

**Handling of IDW.** IDW will consist of purge water, soil, and decontamination water. Purge and decontamination IDW water will be discharged within the containment area of the current Fire Training Facility. The IDW water will not be discharged to the fire training pit if it contains sediment. Soil will be placed in properly labeled Oregon Department of Transportation-approved drums. A sample of the soil will be collected for disposal profiling. The drums will be stored at the designated PDX IDW storage area pending receipt of chemical data. Sampling materials and personal protective equipment will be disposed of as solid waste.

## **5.0 Analytical Program**

Soil and groundwater samples will be analyzed for PFAS by Environmental Protection Agency Method 1663 which includes 40 compounds. This method was finalized for aqueous matrices in July 2023 and all other matrices in January 2024. Samples will be analyzed on a standard turnaround time (approximately 28 days for PFAS). Soil samples that have positive results for field screening (high PID readings, sheen, or free product) will be analyzed for total petroleum hydrocarbons as diesel by Method NWTPH-Dx. The SAP in Appendix B discusses the analytical program in detail.

QA/QC procedures will be used throughout this project. The SAP in Appendix B describes the QA plan for this project, including sampling and custody procedures, QA sampling analyses, detection limit goals, laboratory QC, and QA reporting.

## **6.0 Reporting**

A data report will be prepared presenting the results of the groundwater and soil sampling, a screening of chemical results, discussion of groundwater gradient, and recommendations based on those results.

**Table 1**  
**Groundwater Concentrations**  
**Portland International Airport**  
**Portland, Oregon**

Sample Location	MW-15	MW-27	MW-30	MW-31	MW-33	MW-35	MW-37	MW-11-L58499	MW-12-L58397
Sample Type	Shallow (OD) Monitoring Wells								
Sample Date	11/13/19	11/14/19	11/14/19	11/14/19	11/14/19	11/13/19	11/13/19	11/16/19	11/16/19
Analyte	Concentrations in ng/L								
PFBA	21.3	<64.0	<6.45	73.6	<29.4	<6.52	<6.44	56.8	70.6
PFMPA	<3.17	<32.0	<3.23	<22.9	<14.7	<3.26	<3.22	<3.21	<3.84
3:3 FTCA	<7.94	<80.0	<8.07	<57.1	<36.7	<8.15	<8.05	<8.01	32.6
PFPeA	51.7	<32.0	<3.23	283	<14.7	22.2	<3.22	279	273
PFMBA	<3.17	<32.0	<3.23	<22.9	<14.7	<3.26	<3.22	<3.21	<3.84
PFBS	1.59	<14.2	<1.43	62.5	<6.51	<1.45	<1.43	5.01	9.96
4:2 FTS	<5.95	<60.0	<6.05	<42.9	<27.5	<6.11	<6.04	<6.01	<7.19
PFHxA	40.5	<16.0	<1.61	303	<7.34	16.6	<1.61	266	418
PFEESA	<2.83	<28.5	<2.87	<20.4	<13.1	<2.90	<2.87	<2.85	<3.42
PFPeS	<1.49	<15.0	<1.51	50.9	<6.88	<1.53	<1.51	3.77	16.7
HFPO-DA	<6.63	<66.8	<6.74	<47.7	<30.6	<6.80	<6.72	<6.69	<8.01
NFDHA	<3.17	<32.0	<3.23	<22.9	<14.7	<3.26	<3.22	<3.21	<3.84
5:3 FTCA	<39.7	<400	<40.3	<286	<183	<40.7	<40.3	<40.1	216
PFHpA	32.9	<16.0	<1.61	290	<7.34	7.46	<1.61	94.5	494
ADONA	<6.27	<63.2	<6.37	<45.1	<29.0	<6.44	<6.36	<6.33	<7.58
PFHxS	12.8	<14.6	<1.47	656	<6.70	5.84	<1.47	76.1	646
6:2 FTS	14.1	<60.7	<6.12	<43.4	<27.8	<6.18	<6.11	6.66	724
PFOA	51.6	<20.0	<2.02	1060	<9.17	23.6	<2.01	877	2,770
PFHpS	<1.51	<15.2	<1.53	<10.9	<6.97	<1.55	<1.53	<1.52	3.73
7:3 FTCA	<39.7	<400	<40.3	<286	<183	<40.7	<40.3	<40.1	72.1
PFNA	<1.59	<16.0	<1.61	13.6	<7.34	<1.63	<1.61	<1.60	69.7
PFOSA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	3.43 J
PFOS	1.9	<14.9	<1.50	39	<6.83	1.52 J	<1.50	1.59 J	801
9CI-PF3ONS	<6.19	<62.4	<6.29	<44.6	<28.6	<6.36	<6.28	<6.25	<7.48
PFDA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	26.4
8:2 FTS	<6.09	<61.4	<6.19	<43.9	<28.2	<6.25	<6.18	<6.15	1,220
PFNS	<1.53	<15.4	<1.55	<11.0	<7.06	<1.57	<1.55	<1.54	<1.85
MeFOSAA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
EtFOSAA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
PFUnA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
PFDS	<1.53	<15.4	<1.55	<11.0	<7.06	<1.57	<1.55	<1.54	<1.85
11CI-PF3OUdS	<5.95	<60.0	<6.05	<42.9	<27.5	<6.11	<6.04	<6.01	<7.19
PFDoA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
MeFOSA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
PFTTrDA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
PFDoS	<1.54	<15.5	<1.56	<11.1	<7.11	<1.58	<1.56	<1.55	<1.86
PFTeDA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
EtFOSA	<1.59	<16.0	<1.61	<11.4	<7.34	<1.63	<1.61	<1.60	<1.92
MeFOSE	<15.9	<160	<16.1	<114	<73.4	<16.3	<16.1	<16.0	<19.2
EtFOSE	<15.9	<160	<16.1	<114	<73.4	<16.3	<16.1	<16.0	<19.2

Please see notes at end of table.

**Table 1**  
**Groundwater Concentrations**  
**Portland International Airport**  
**Portland, Oregon**

Sample Location	B-1	B-2	B-3		B-4		B-5	TA-01	TA-02
Sample Type	Temporary Borings								
Sample Date	12/04/2024	12/04/2024	11/13/2023	12/04/2024	11/13/2023	12/04/2024	12/04/2024	01/22/2024	01/22/2024
Analyte	Concentrations in ng/L								
PFBA	<13.8	<114	<22.4	<61.5	1.59	<9.30	<400	12	4.1 J
PFMPA	<5.89	<48.8	<11.2	<26.3	<3.19	<3.97	<171	<0.42	<0.41
3:3 FTCA	<13.6	<113	<28.0	<60.8	<7.97	<9.19	<395	<6.9	<6.8
PFPeA	<3.61	<29.9	<11.2	<16.1	0.417	<2.44	<105	9.7	12
PFMBA	<3.89	<32.2	<11.2	<17.3	<3.19	<2.62	<113	<0.55	<0.54
PFBS	<5.82	<48.2	<4.97	<26.0	0.673	<3.92	<169	1.2 J	0.63 J
4:2 FTS	<10.9	<90.7	<21.0	<48.8	<5.98	<7.38	<318	<0.43	<0.42
PFHxA	<2.35	<19.5	<5.59	<10.5	0.272	<1.59	<68.3	7.8	5.7
PFEESA	<3.21	<26.6	<9.97	<14.3	<2.84	<2.16	<93.0	<0.44	<0.43
PFPeS	<4.17	<34.6	<5.24	<18.6	<1.49	<2.81	<121	<0.9	<0.89
HFPO-DA	<14.7	<121	<23.4	<65.4	<6.66	<9.88	<425	<0.42	<0.41
NFDHA	<13.4	<111	<11.2	<59.6	<3.19	<9.01	<388	<0.59	<0.58
5:3 FTCA	<58.4	<484	<140	<260	<39.9	<39.4	<1,690	<4.3	<4.2
PFHpA	<2.34	<19.4	<5.59	<10.4	0.270	<1.58	<67.8	5.2	3.2 J
ADONA	<13.7	<114	<22.1	<61.2	<6.30	<9.24	<398	<0.37	<0.36
PFHxS	<4.34	<36.0	<5.10	<19.4	0.502	<2.93	<126	5.8	1.6 J
6:2 FTS	<10.5	<87.1	<21.2	<46.9	<6.05	<7.09	<305	<1.4	<1.3
PFOA	<15.3	<127	<6.99	<68.5	1.77	19.0	<445	110	11
PFHpS	<3.25	<26.9	<5.31	<14.5	<1.51	<2.19	<94.3	<0.7	<0.69
7:3 FTCA	<30.9	<256	<140	<138	<39.9	<20.9	<897	<6.1	<6
PFNA	<2.09	<17.3	<5.59	<9.31	0.241	<1.41	<60.5	3.8 J	2.5 J
PFOSA	<3.43	<28.4	<5.59	<15.3	<1.59	<2.31	<99.5	<0.73	<0.72
PFOS	<10.1	<83.6	<5.21	<45.0	1.17	<6.80	<293	6.1	5.9
9CI-PF3ONS	<16.6	<137	<21.8	<73.8	<6.22	<11.2	<480	<0.46	<0.45
PFDA	<3.66	<30.4	<5.59	<16.3	<1.59	<2.47	<106	4.7 J	1.3 J
8:2 FTS	<16.1	<134	<21.5	<71.9	<6.12	<10.9	<468	<0.87	<0.86
PFNS	<5.21	<43.1	<5.38	<23.2	<1.53	<3.51	<151	<0.34	<0.33
MeFOSAA	<5.96	<49.4	<5.59	<26.6	<1.59	<4.02	<173	<0.92	<0.91
EtFOSAA	<5.94	<49.2	<5.59	<26.5	<1.59	<4.01	<172	<0.97	<0.95
PFUnA	<3.56	<29.5	<5.59	<15.9	<1.59	<2.40	<103	3.3 J	<0.82
PFDS	<4.86	<40.3	<5.38	<21.7	<1.53	<3.28	<141	<0.68	<0.67
11CI-PF3OUdS	<16.6	<138	<21.0	<74.2	<5.98	<11.2	<483	<0.4	<0.39
PFDoA	<1.92	<15.9	<5.59	<8.58	<1.59	<1.30	<55.8	8	<0.61
MeFOSA	<8.71	<72.1	<5.59	<38.8	<1.59	<5.87	<253	<1.3	<1.2
PFTTrDA	<2.21	<18.3	<5.59	<9.85	<1.59	<1.49	<64.0	2.3 J	<0.46
PFDoS	<4.28	<35.5	<5.42	<19.1	<1.54	<2.89	<124	<0.57	<0.56
PFTeDA	<2.06	<17.1	<5.59	<9.19	<1.59	<1.39	<59.8	2.5 J	<1.3
EtFOSA	<13.8	<114	<5.59	<61.5	<1.59	<9.30	<400	<0.86	<0.85
MeFOSE	<138	<1,140	<55.9	<615	<15.9	<93.0	<4,000	<0.83	<0.82
EtFOSE	<138	<1,140	<55.9	<615	<15.9	<93.0	<4,000	<0.94	<0.92

Please see notes at end of table.



**Table 1**  
**Groundwater Concentrations**  
**Portland International Airport**  
**Portland, Oregon**

**Notes:**

1. ng/L = nanograms per liter (ppt [parts per trillion]).
2. Bold values indicate the compounds was detected above laboratory limits.
3. < = Compound not detected at or above reporting limit (for samples collected on 11/13/2023) or method detection limit (for samples collected on 12/4/2023)


<b>PFBA:</b> Perfluorobutanoic acid (C4)	<b>PFNA:</b> Perfluorononanoic acid (C9)
<b>PFMPA:</b> Perfluoro-3-methoxypropanoic acid	<b>PFOSA:</b> Perfluorooctane sulfonamide (C8)
<b>3:3 FTCA:</b> 3-Perfluoropropyl Propanoic acid	<b>PFOS:</b> Perfluorooctane sulfonic acid (C8)
<b>PFPeA:</b> Perfluoropentanoic acid (C5)	<b>9CI-PF3ONS:</b> 9-Chlorohexadecafluoro-3-oxanone-1-sulfonic acid (F-53B major)
<b>PFMBA:</b> Perfluoro(4-methoxybutanoic) acid	<b>PFDA:</b> Perfluorodecanoic acid (C10)
<b>PFBS:</b> Perfluorobutane sulfonic acid (C4)	<b>8:2 FTS:</b> Fluorotelomer sulfonate (C8)
<b>4:2 FTS:</b> Fluorotelomer sulfonate (C4)	<b>PFNS:</b> Perfluorononane sulfonic acid (C9)
<b>PFHxA:</b> Perfluorohexanoic acid (C6)	<b>MeFOSAA:</b> Methyl perfluorooctanesulfonamidoacetic acid (C8)
<b>PFEEA:</b> Perfluoro(2-ethoxyethane)sulphonic acid	<b>EtFOSAA:</b> Ethyl perfluorooctanesulfonamidoacetic acid (C8)
<b>PFPeS:</b> Perfluoropentane sulfonic acid (C5)	<b>PFUnA:</b> Perfluoroundecanoic acid (C11)
<b>HFPO-DA:</b> Hexafluoropropylene oxide-dimer acid (GenX)	<b>PFDS:</b> Perfluorodecane sulfonic acid (C10)
<b>NFDHA:</b> Nonafluoro-3,6-dioxaheptanoic acid	<b>11CI-PF3OUdS:</b> 11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid (F-53B minor)
<b>5:3 FTCA:</b> 5:3 Fluorotelomer carboxylic acid	<b>PFDoA:</b> Perfluorododecanoic acid (C12)
<b>PFHpA:</b> Perfluoroheptanoic acid (C7)	<b>MeFOSA:</b> Methylperfluorooctanesulfonamide
<b>ADONA:</b> 4,8-Dioxa-3H-perfluorononanoate	<b>PFTTrDA:</b> Perfluorotridecanoic acid (C13)
<b>PFHxS:</b> Perfluorohexane sulfonic acid (C6)	<b>PFDoS:</b> Perfluorodecane Sulfonic Acid
<b>6:2 FTS:</b> Fluorotelomer sulfonate (C6)	<b>PFTeDA:</b> Perfluorotetradecanoic acid (C14)
<b>PFOA:</b> Perfluorooctanoic acid (C8)	<b>EtFOSA:</b> Ethylperfluorooctanesulfonamide
<b>PFHpS:</b> Perfluoroheptane sulfonic acid (C7)	<b>MeFOSE:</b> Methylperfluorooctanesulfonamidoethanol
<b>7:3 FTCA:</b> 7:3 Fluorotelomer carboxylic acid	<b>EtFOSE:</b> Ethyl perfluorooctane sulfonamido ethanol

**Table 2**  
**Former Fire Stations Site Characterization Plan**  
**Portland International Airport**  
**Portland, Oregon**

Water Bearing Zone	Work Phase	Well ID	Well Screen Interval (ft bgs)	Well Log ID
Overbank Deposit (OD)	Existing	MW-1	5-20	MULT_111765
		MW-6	5-15	MULT_64211
		MW-8	5-15	MULT_68450
		MW-11-L58501	5-20	MULT_68452
		MW-12-L58397	5-20	MULT_68922
		MW-14	5-20	MULT_68924
	Proposed	MW-101	--	--
		MW-102	--	--
Columbia River Sand Aquifer (CRSA)	Existing	TCORE-3	117-135	MULT_135484
	Proposed	DW-101	--	--
		DW-102	--	--

**Notes:**

1. TCORE = Terminal Core Redevelopment
2. ft bgs = feet below ground surface



**Note:** Base map prepared from USGS 7.5-minute quadrangle of Portland and Mount Tabor, WA-OR, dated 2024 as provided by USGS.gov.

0 4,000 8,000  
Approximate Scale in Feet



## Site Location Map

Former Fire Stations Site Characterization Work Plan  
Port of Portland  
Portland, Oregon



Apex Companies, LLC  
15618 SW 72nd Avenue  
Tigard, Oregon 97224


Project Number: 32-24009923  
Drawn: JP  
Approved: CO

November 2024

Figure

1







Legend:


- MW-8

Existing Overbank Deposit (OD)  
Monitoring Well Location
- TA-01

Shallow Temporary Boring Location
- 15.12

Groundwater Elevation in Feet MSL
- 15

Groundwater Elevation Contour
- Apparent Groundwater Flow Direction
- Underground Storm Sewer Pipeline
- Underground Subdrain Sewer Pipeline
- Abandoned Storm Sewer Pipeline
- Catch Basin
- Manhole
- Cleanout



Note: Base map prepared from a 2013 Port of Portland AutoCAD base and Oregon Metro [www.oregonmetro.gov/rliis](http://www.oregonmetro.gov/rliis).

Shallow (OD) Groundwater Elevations  
Contour Map (May 2023)

Former Fire Stations Site Characterization Work Plan  
Port of Portland  
Portland, Oregon

Apex Companies, LLC  
15618 SW 72nd Avenue  
Tigard, Oregon 97224

Project Number: 32-24009923  
Drawn: JP  
Approved: CO  
November 2024

Figure  
3



Legend:


- MW-8

Existing Overbank Deposit (OD)  
Monitoring Well Location
- TA-01

Shallow Temporary Boring Location
- 16.73

Groundwater Elevation in Feet MSL
- 11

Groundwater Elevation Contour
- Apparent Groundwater Flow Direction
- Underground Storm Sewer Pipeline
- Underground Subdrain Sewer Pipeline
- Abandoned Storm Sewer Pipeline
- Catch Basin
- Manhole
- Cleanout



Note: Base map prepared from a 2013  
Port of Portland AutoCAD base and  
Oregon Metro [www.oregonmetro.gov/rlls](http://www.oregonmetro.gov/rlls).

**Shallow (OD) Groundwater Elevations  
Contour Map (November 2023)**  
Former Fire Stations Site Characterization Work Plan  
Port of Portland  
Portland, Oregon




Apex Companies, LLC  
15618 SW 72nd Avenue  
Tigard, Oregon 97224

Project Number: 32-24009923	Drawn: JP	Approved: CO	Figure 4
November 2024			




Legend:


- TCORE-3




Existing Columbia River Sand Aquifer (CRSA) Monitoring Well Location
- TA-01





Shallow Temporary Boring Location
- 13.52





Groundwater Elevation in Feet MSL
- 13.55





Groundwater Elevation Contour
- 


Apparent Groundwater Flow Direction
- 

Underground Storm Sewer Pipeline
- 


Underground Subdrain Sewer Pipeline
- 

Abandoned Storm Sewer Pipeline
- 

Catch Basin
- 

Manhole
- 

Cleanout



**Note:** Base map prepared from a 2013 Port of Portland AutoCAD base and Oregon Metro [www.oregonmetro.gov/rliis](http://www.oregonmetro.gov/rliis).

**Deep (CRSA) Groundwater Elevations Contour Map (May 2023)**  
Former Fire Stations Site Characterization Work Plan  
Port of Portland  
Portland, Oregon

Apex Companies, LLC  
15618 SW 72nd Avenue  
Tigard, Oregon 97224

Project Number:	32-24009923	Drawn:	JP	Approved:	CO
November 2024					

Figure  
**5**



Legend:

- MW-8

Existing Overbank Deposit (OD) Monitoring Well Location
- TCORE-3

Existing Columbia River Sand Aquifer (CRSA) Monitoring Well Location
- TA-01

Shallow Temporary Boring Location
- Location Identification
- Date Sampled
- Concentration in Nanograms per Liter (ng/L, ppt)
- Analyte Sampled
- ND = Not Detected
- Underground Storm Sewer Pipeline
- Underground Subdrain Sewer Pipeline
- Abandoned Storm Sewer Pipeline
- Catch Basin
- Manhole
- Cleanout

Abbreviations		Unit
PFOS	Perfluorooctane Sulfonic Acid	ng/L
PFOA	Perfluorooctanoic Acid	ng/L

MW-35		
11/14/2023		
PFOS	1.52	
PFOA	23.6	

MW-27		
11/15/2023		
PFOS	<14.9	
PFOA	<20.0	

MW-30		
11/15/2023		
PFOS	<1.50	
PFOA	<2.02	

MW-31		
11/15/2023		
PFOS	39.0	
PFOA	1,060	

MW-33		
11/15/2023		
PFOS	<6.83	
PFOA	<9.17	

MW-35		
11/14/2023		
PFOS	1.52	
PFOA	23.6	

MW-15		
11/14/2023		
PFOS	1.90	
PFOA	51.6	

MW-37		
11/14/2023		
PFOS	<1.50	
PFOA	<2.01	

TA-01		
1/22/2024		
PFOS	6.1	
PFOA	110	

TA-02		
1/22/2024		
PFOS	5.9	
PFOA	11	

MW-11-L58499		
11/17/2023		
PFOS	1.59	
PFOA	877	

MW-12-L58397		
11/17/2023		
PFOS	801	
PFOA	2,770	

B-1		
12/4/2023		
PFOS	ND	
PFOA	ND	

B-4		
12/4/2023		
PFOS	1.17	
PFOA	19.0	

B-2		
12/4/2023		
PFOS	ND	
PFOA	ND	

B-3		
12/4/2023		
PFOS	ND	
PFOA	ND	

B-5		
12/4/2023		
PFOS	ND	
PFOA	ND	

Note: Base map prepared from a 2013 Port of Portland AutoCAD base and Oregon Metro [www.oregonmetro.gov/rliis](http://www.oregonmetro.gov/rliis).

PFOS and PFOA in Shallow (OD) Groundwater

Former Fire Stations Site Characterization Work Plan  
Port of Portland  
Portland, Oregon

0 600 1,200

Scale in Feet

Apex Companies, LLC  
15618 SW 72nd Avenue  
Tigard, Oregon 97224


Project Number: 32-24009923  
November 2024

Figure 6




Legend:


- MW-8




Existing Overbank Deposit (OD)  
Monitoring Well Location
- TCORE-3




Existing Columbia River Sand Aquifer  
(CRSA) Monitoring Well Location
- TA-01




Shallow Temporary Boring Location
- MW-102





Proposed OD Monitoring Well Location
- DW-101





Proposed CRSA Monitoring Well Location
- B-6





Proposed Boring Location
- 

Underground Storm Sewer Pipeline
- 


Underground Subdrain Sewer Pipeline
- 

Abandoned Storm Sewer Pipeline
- 

Catch Basin
- 

Manhole
- 

Cleanout



Former Fire Stations Proposed  
Well and Boring Locations

Former Fire Stations Site Characterization Work Plan  
Port of Portland  
Portland, Oregon

Apex Companies, LLC  
15618 SW 72nd Avenue  
Tigard, Oregon 97224

Project Number:	32-24009923	Drawn:	JP	Approved:	CO
November 2024					

Figure  
7

## ***Appendix A***

---

### **Monitoring Well Logs**

Start Card # 134984

~~DEPARTMENT OF ECOLOGY~~

## (b) LOCATION OF WELL By legal description

Well Location: County Polk  
Township 1 (N or S) Range 24 (E or W) Section 8  
1. NE 1/4 of NW 1/4 of above section.  
2. Either Street address of well location same

**3. ATTACH MAP WITH LOCATION IDENTIFIED.** Map shall include approximate scale and north arrow.

(7) STATIC WATER LEVEL:

10 Ft. below land surface. Date 5/29/01  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

**(8) WATER BEARING ZONES:**

Depth at which water was first found 10

From	To	Est. Flow Rate	SWL
10	15		10

Ground elevation \_\_\_\_\_

[illegible]

Date started 5/24/01 Completed 5/24/01

**WELL TEST:**  
☐ Pump ☐ Bailer ☐ Air ☐ Flowing Artesian  
 Permeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM  
 Conductivity \_\_\_\_\_ PH \_\_\_\_\_  
 Temperature of water 51 °F/C Depth artesian flow found \_\_\_\_\_ ft.  
 Was water analysis done? ☒ Yes ☐ No  
 By whom? \_\_\_\_\_  
 Depth of strata to be analyzed. From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Remarks: \_\_\_\_\_

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon well construction standards. Materials used and information reported above are true to the best knowledge and belief.

MWC Number 105

Signed Carlos Anguiano

MWC Number 10500  
Date 6/19/01

(bonded) Monitor Well Constructor Certification:

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon well construction standards. This report is true to the best of my knowledge and belief.

Signed Brian K. Hester MWC Number 1044  
 Date 6/19/01  
 SECOND COPY-CONSTRUCTOR THIRD COPY-CUSTOMER

ORIGINAL & FIRST COPY-WATER RESOURCES DEPARTMENT


Proposed Monitoring Well Locations  
PDX, Terminal Expansion South  
Port of Portland

**RECEIVED**

JUL 03 2001

WATER RESOURCES DEPT  
SALEM, OREGON

MULT 64211



Note: Base map prepared from an AutoCAD map provided by the Port of Portland

**Legend:**

MW-T14 Temporary Well Location and Designation

B-12 Boring Location and Designation

CR-37+ Geoprobe Exploration Location and Designation

Highest TPH-D (Jet Fuel) Concentration in Soil in mg/kg (Sample Interval in Feet BGS)

TPH-D (Jet Fuel) Concentration in Groundwater in mg/L

Construction Oversight Soil Sample Location and Designation  
(Sample Locations Without Designation were ND)

Petroleum Hydrocarbons Not Detected

Proposed TES Phase II Monitoring Well Location

Existing Underground Fuel Line

Former Underground Fuel Line

New Underground Fuel Line

Gate Number

0 50 100 200  
Approximate Scale in Feet



**HART-CROWSER**  
15141-00  
4/01  
Figure 3

Instructions for completing this report are on the last

Instructions for completing this report are on the last page of this form. **Amended Well Report** 

MULT 68450  
MULT 00450  
MULT 00450

Weil UD#

L58496

Start Card # 154598


WELL NO. MW08

Address 7120 N12 Airport Way.  
City Perth Amboy State OK Zip 97218

☒ New construction      ☐ Alteration (Repair/Recondition)  
☐ Conversion      ☐ Deepening      ☐ Abandonment

☐ Rotary Air                      ☐ Rotary Mud                      ☐ Cable  
☐ Hollow Stem Auger           ☒ Other Push Probe

Special Standards Yes ☐ No ☒ Depth of Completed Well 15 ft.



<input type="checkbox"/> Pump	<input type="checkbox"/> Bailer	<input type="checkbox"/> Air	<input type="checkbox"/> Flowing Artesian
Permeability _____	Yield _____	GPM	
Conductivity _____	PH _____		
Temperature of water	54	100° Depth artesian flow found	
Was water analysis done?	<input type="checkbox"/> Yes	<input checked="" type="checkbox"/> No	

By whom? \_\_\_\_\_

Depth of strata to be analyzed. From \_\_\_\_\_ ft to \_\_\_\_\_ ft

Remarks: \_\_\_\_\_

Name of supervising Geologist/Engineer

County Multnomah Latitude \_\_\_\_\_ Longitude \_\_\_\_\_  
Township 1 (N or S) Range 2 (E or W) Section 8  
SE 1/4 of SW 1/4 of above section.  
Street address of well location 7120 N/E Airport Way

Tax lot number of well location 300  
ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include  
approximate scale and north arrow.

9.6 Ft. below land surface. Date 1/7/03  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

[illegible]

## Ground Elevation \_\_\_\_\_

Material	From	To	SW
Silky sand	0	15	9.1
JUL 24 2003			
<b>RECEIVED</b> FEB 05 2003 WATER RESOURCES DEPT SALEM, OREGON			

Date started 1/7/03 Completed 1/7/03

**(unbounded) Monitor Well Constructor Certification:**

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed [Signature] Date 2/3/03

### **Grounded Monitor Well Constructor Certification:**

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] Date 2/3/13

ORIGINAL COPY - WATER RESOURCES DEPARTMENT

FIRST COPY CONSTRUCTOR SECOND COPY CUSTOMER



# MONITORING WELL REPORT

(as required by ORS 537.765 & OAR 690-240-095)

MULT. 68450

Well ID#

L58496

Instructions for completing this report are on the last page of this form. Amended Well Report

Start Card # 154598

## (1) OWNER/PROJECT

WELL NO. MW10  
Name Port of Portland  
Address 7120 NE Airport Way  
City Portland State OR Zip 97218

## (2) TYPE OF WORK


☒ New construction ☐ Alteration (Repair/Recondition)  
☐ Conversion ☐ Deepening ☐ Abandonment

## (3) DRILLING METHOD

☐ Rotary Air ☐ Rotary Mud ☐ Cable  
☐ Hollow Stem Auger ☒ Other Push Probe

## (4) BORE HOLE CONSTRUCTION:

Special Standards Yes No ☒ Depth of Completed Well 15 ft.



## (5) WELL TESTS:

☐ Pump ☐ Bailor ☐ Air ☐ Flowing Artesian  
Permeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM  
Conductivity \_\_\_\_\_ PH \_\_\_\_\_  
Temperature of water 54 F/C Depth artesian flow found \_\_\_\_\_ ft.  
Was water analysis done? ☐ Yes ☒ No  
By whom? \_\_\_\_\_  
Depth of strata to be analyzed. From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
Remarks: \_\_\_\_\_

Name of supervising Geologist/Engineer \_\_\_\_\_

## (6) LOCATION OF WELL By legal description:

County Multnomah Latitude \_\_\_\_\_ Longitude \_\_\_\_\_  
Township 1 (N or S) Range 2 (E or W) Section 8  
SE 1/4 of SW 1/4 of above section.  
Street address of well location 7120 NE Airport Way

Tax lot number of well location 300

ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include approximate scale and north arrow.

## (7) STATIC WATER LEVEL:

9.6 ft. below land surface. Date 1/7/03  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

## (8) WATER BEARING ZONES:

From	To	Est. Flow Rate	SW
9.6	15		9.6

## (9) WELL LOG:

Ground Elevation \_\_\_\_\_

Material	From	To	SW
Silty sand	0	15	9.6

RECEIVED

FEB 05 2003

WATER RESOURCES DEPT  
SALEM, OREGON

Date started 1/7/03 Completed 1/7/03

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed [Signature] Date 2/3/03

(bonded) Monitor Well Constructor Certification:

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 10011 Date 2/3/03

ORIGINAL COPY - WATER RESOURCES DEPARTMENT

FIRST COPY - CONSTRUCTOR SECOND COPY - CUSTOMER


Instructions for completing this report are on the last page of this form.

City Portland State OR Zip 97218

☐ Alteration (Repair/Recondition)  
☐ Deepening                      ☐ Abandonment

☒ Other Push Probe

Special Standards      Yes    No      Depth of Completed Well 15 ft.



Remarks:

ORIGINAL COPY - WATER RESOURCES DEPARTMENT

ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include approximate scale and north arrow

Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

Depth at which water was first found

[illegible]

Ground Elevation

Material	From	To	SWL
Silly Samel	0	15	9.6
<b>RECEIVED</b> <b>FEB 05 2003</b> <b>WATER RESOURCES DEPT</b> <b>SALEM, OREGON</b>			

Date started 1/7/03 Completed 1/7/03

(umbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.


Signed B. R. Galt 10443  
Date 2/3/83

(bonded) Monitor Well Constructor Certification);

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 70817  
Date 2/3/43  
T COPY CONSTRUCTOR SECOND COPY CUSTOMER

MULT 68450



**RECEIVED**

FEB 05 2003

WATER RESOURCES DEPT  
SALEM, OREGON



## Well Report

Well ID# L58499

Start Card # 154601

Instructions for completing this report are on the last page of this form.

**(6) LOCATION OF WELL** By legal description:

County Multnomah Latitude \_\_\_\_\_ Longitude \_\_\_\_\_

Township 1 (N or S) Range 2 (E or W) Section 8

SE 1/4 of SW 1/4 of above section.

Street address of well location 7120 NE Airport Way

Tax lot number of well location 300

**ATTACH MAP WITH LOCATION IDENTIFIED.** Map shall include approximate scale and north arrow.

**(7) STATIC WATER LEVEL:**

☐ Rotary Air      ☐ Rotary Mud      ☐ Cable

☐ Hollow Stem Auger ☒ Other Push Probe

8.78 Ft. below land surface.

Date 1/7/03


Artesian Pressure \_\_\_\_\_ lb/sq. in.

Date \_\_\_\_\_

**(8) WATER BEARING ZONES:**

Special Standards      Yes ☐ No ☒      Depth of Completed Well 20 ft.

Depth at which water was first found 8.75



**(9) WELL LOG:**

### Ground Elevation

[illegible]

Date started 1/7/03 Completed 1/7/03

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed B. R. Galt Date 2/3/03

(bonded) Monitor Well Constructor Certification:

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 10011  
Date 2/2/43

**(5) WELL TESTS:**

☐ Pump      ☐ Bailer      ☐ Air      ☐ Flowing Artesian

Permeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM \_\_\_\_\_

Conductivity \_\_\_\_\_ PH \_\_\_\_\_

Temperature of water 54 °F/C Depth artesian flow found \_\_\_\_\_ ft.

Was water analysis done? ☐ Yes ☒ No

### By whom?

Depth of strata to be analyzed, From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.

Remarks: \_\_\_\_\_

Name of supervising Geologist/Engineer \_\_\_\_\_

ORIGINAL COPY – WATER RESOURCES DEPARTMENT

~~FIRST COPY - CONSTRUCTOR~~      ~~SECOND COPY~~      ~~CUSTOMER~~

MULT 68452

(as required by ORS 537.765 & OAR 690-240-095)

Instructions for completing this report are on the last page of this form.

Well ID# L58499  
Start Card # 154601

**(1) OWNER/PROJECT**

Name Port of Portland Address 7120 NE Airport Way  
City Portland State OR Zip 97218

## (2) TYPE OF WORK


☒ New construction      ☐ Alteration (Repair/Recondition)  
☐ Conversion      ☐ Deepening      ☐ Abandonment

### (3) DRILLING METHOD

☐ Rotary Air      ☐ Rotary Mud      ☐ Cable  
☐ Hollow Stem Auger      ☒ Other Push Probe

**(4) BORE HOLE CONSTRUCTION:**

Special Standards      Yes ☐    No ☒    Depth of Completed Well 20 ft.



**(5) WELL TESTS:**

☐ Pump      ☐ Bailer      ☐ Air      ☐ Flowing Artesian  
 Permeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM  
 Conductivity \_\_\_\_\_ PH \_\_\_\_\_  
 Temperature of water 54 °F/C    Depth artesian flow found \_\_\_\_\_ ft.  
 Was water analysis done?    ☐ Yes    ☒ No  
 By whom? \_\_\_\_\_  
 Depth of strata to be analyzed. From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Remarks: \_\_\_\_\_

Name of supervising Geologist/Engineer \_\_\_\_\_

**(6) LOCATION OF WELL** By legal description:

County Multnomah Latitude \_\_\_\_\_ Longitude \_\_\_\_\_  
Township 1 (N or S) Range 2 (E or W) Section 8  
SE 1/4 of SW 1/4 of above section.  
Street address of well location 7120 NE Airport Way

Tax lot number of well location 300  
ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include  
approximate scale and north arrow.

**(7) STATIC WATER LEVEL:**

8.75 Ft. below land surface. Date 1/7/03  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

**(8) WATER BEARING ZONES:**

Depth at which water was first found 8.75

From	To	Est. Flow Rate	SWL
8.75	20		8.75

**(9) WELL LOG:**

Ground Elevation \_\_\_\_\_

[illegible]

Date started 1/7/03 Completed 1/7/03

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed [Signature] Date 2/3/23


(banded) Monitor Well Constructor Certification:

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 10011  
Date 2/2/03

ORIGINAL COPY – WATER RESOURCES DEPARTMENT

FIRST COPY - CONSTRUCTOR      SECOND COPY - CUSTOMER



**RECEIVED**

FEB 05 2003

WATER RESOURCES DEPT  
SALEM, OREGON

FAA CONTROLLED MOVEMENT AREA

MULT 68922

## Amended Well Report

Well ID# L 38297  
Start Card # 154690

(6) LOCATION OF WELL By legal description:  
County Mult Latitude \_\_\_\_\_ Longitude \_\_\_\_\_  
Township 1 (N or S) Range 2 (E or W) Section 8  
SE 1/4 of NW 1/4 of above section.  
Street address of well location 7120 NE Airport Way

☒ New construction      ☐ Alteration (Repair/Recondition)  
☐ Conversion      ☐ Deepening      ☐ Abandonment

Tax lot number of well location 300


ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include approximate scale and north arrow.

☐ Rotary Air      ☐ Rotary Mud      ☐ Cable  
☐ Hollow Stem Auger      ☒ Other Push Probe

8.91 Ft. below land surface. Date 2/15/03  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

Special Standards ☐ Yes ☒ No Depth of Completed Well 20 ft.

Depth at which water was first found 8.97



From	To	Est. Flow Rate	SWI
8.97	20		8.97

### Ground Elevation

[illegible]

Date started 2/14/03 Completed 2/15/03

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed B. R. Galt Date 3/3/03

**(bonded) Monitor Well Constructor Certification:**

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 10011  
Date 2/12/03

**(5) WELL TESTS:**

☐ Pump      ☐ Bailer      ☐ Air      ☐ Flowing Artesian

Permeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM \_\_\_\_\_

Conductivity \_\_\_\_\_ PH \_\_\_\_\_

Temperature of water 54 °F/C Depth artesian flow found \_\_\_\_\_ ft

Was water analysis done? ☐ Yes ☒ No

By whom? \_\_\_\_\_

Depth of strata to be analyzed. From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.

Remarks:


100% (100%)

Name of supervising Geologist/Engineer \_\_\_\_\_

ORIGINAL COPY - WATER RESOURCES DEPARTMENT

FIRST COPY - CONSTRUCTOR      SECOND COPY - CUSTOMER





**RECEIVED**

MAR 14 2003

WATER RESOURCES DEPT.  
SALEM, OREGON

MULT 68924  
MULT 68924

## Amended Well Report

Well ID# L58399  
Start Card # 154692

**(6) LOCATION OF WELL** By legal description:

County Helf Latitude \_\_\_\_\_ Longitude \_\_\_\_\_  
Township 1 (N or S) Range 20 (E or W) Section 8  
SE 1/4 of NW 1/4 of above section.  
Street address of well location 7170 NE Airport Way

☒ New construction      ☐ Alteration (Repair/Recondition)  
☐ Conversion      ☐ Deepening      ☐ Abandonment

Tax lot number of well location 300  
ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include  
approximate scale and north arrow.

☐ Rotary Air      ☐ Rotary Mud      ☐ Cable  
☐ Hollow Stem Auger      ☒ Other Push Probe

(7) **STATIC WATER LEVEL:**

8.91 Ft. below land surface. Date 2/15/03  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

Special Standards ☐ Yes ☒ No Depth of Completed Well 20 ft.

**(8) WATER BEARING ZONES:**

Depth at which water was first found 8.97

**Vault**

0 ft.

70 ft.

**Seal**

1 ft.

TO

4 ft.

**Filter pack**

4 ft.

20 ft.

Land surface

Water-tight cover

Surface flush vault

Locking cap

Casing diameter 1 in.

material PVC

Welded Threaded Glued

☐ ☒ ☐

Liner diameter \_\_\_\_\_ in.

material \_\_\_\_\_

Welded Threaded Glued

☐ ☐ ☐

Well seal:

Material 3-25 Bentonite

Amount 1 lb

Grout weight \_\_\_\_\_

Borehole diameter 3.05 in.

Bentonite plug at least 3 ft. thick

Screen material PVC

interval(s):

From 5 To 20

From \_\_\_\_\_ To \_\_\_\_\_

Slot size 10/10 in.

Filter pack:

Material Sand

Size 10-20 in.

From	To	Est. Flow Rate	SWI
8.97	20		8.97

**(9) WELL LOG:**

[illegible]

Date started 2/14/03 Completed 2/15/03

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed Bruce L. Galt Date 3/3/03

(bonded) Monitor Well Constructor Certification:

I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 10011  
Date 2/13/03

**(5) WELL TESTS:**

☐ Pump      ☐ Bailer      ☐ Air      ☐ Flowing ArtesianPermeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM \_\_\_\_\_

Conductivity \_\_\_\_\_ PH \_\_\_\_\_  
Temperature of water 54 °F/C Depth artesian flow found \_\_\_\_\_ ft

Was water analysis done? ☐ Yes ☒ No

By whom? \_\_\_\_\_

Depth of strata to be analyzed. From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.

Remarks: \_\_\_\_\_

\_\_\_\_\_

Name of supervising Geologist/Engineer \_\_\_\_\_

ORIGINAL COPY - WATER RESOURCES DEPARTMENT

FIRST COPY - CONSTRUCTOR      SECOND COPY - CUSTOMER

## MONITORING WELL REPORT

(as required by ORS 537.765 & OAR 690-240-095)

Instructions for completing this report are on the last page of this form.

Well ID# L58399  
Start Card # 154692

Start Card # 154692

**(1) OWNER/PROJECT**

Name Port of Portland  
Address 7120 NE Airport Way  
City Portland State OR Zip 97218

## (2) TYPE OF WORK


☒ New construction      ☐ Alteration (Repair/Recondition)  
☐ Conversion      ☐ Deepening      ☐ Abandonment

### (3) DRILLING METHOD

☐ Rotary Air      ☐ Rotary Mud      ☐ Cable  
☐ Hollow Stem Auger      ☒ Other Push Probe

**(4) BORE HOLE CONSTRUCTION:**

Special Standards ☐ Yes ☒ No Depth of Completed Well 20 ft.



**(5) WELL TESTS:**

☐ Pump      ☐ Bailer      ☐ Air      ☐ Flowing Artesian  
 Permeability \_\_\_\_\_ Yield \_\_\_\_\_ GPM  
 Conductivity \_\_\_\_\_ PH \_\_\_\_\_  
 Temperature of water 59 °F/C      Depth artesian flow found \_\_\_\_\_ ft.  
 Was water analysis done?    ☐ Yes    ☒ No  
 By whom? \_\_\_\_\_  
 Depth of strata to be analyzed. From \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Remarks: \_\_\_\_\_

Name of supervising Geologist/Engineer

**(6) LOCATION OF WELL** By legal description:

County Holt Latitude \_\_\_\_\_ Longitude \_\_\_\_\_  
Township 1 (N or S) Range 20 (E or W) Section 8  
SE 1/4 of NW 1/4 of above section.  
Street address of well location 7120 NE Airport Way

Tax lot number of well location 300

ATTACH MAP WITH LOCATION IDENTIFIED. Map shall include approximate scale and north arrow.

(7) **STATIC WATER LEVEL:**

8.97 Ft. below land surface. Date 2/15/03  
Artesian Pressure \_\_\_\_\_ lb/sq. in. Date \_\_\_\_\_

**(8) WATER BEARING ZONES:**

Depth at which water was first found 8.97

From	To	Est. Flow Rate	SWL
8.97	20		8.77

**(9) WELL LOG:**

Ground Elevation

[illegible]

Date started 2/14/03 Completed 2/15/03

(unbonded) Monitor Well Constructor Certification:

I certify that the work I performed on the construction, alteration, or abandonment of this well is in compliance with Oregon water supply well construction standards. Materials used and information reported above are true to the best of my knowledge and belief.

Signed B. R. Galt Date 3/3/03

(bonded) Monitor Well Constructor Certification:


I accept responsibility for the construction, alteration, or abandonment work performed on this well during the construction dates reported above. All work performed during this time is in compliance with Oregon water supply well construction standards. This report is true to the best of my knowledge and belief.

Signed [Signature] MWC Number 10011  
Date 2/18/03

ORIGINAL COPY – WATER RESOURCES DEPARTMENT

FIRST COPY – CONSTRUCTOR      SECOND COPY – CUSTOMER





**RECEIVED**

MAR 14 2003

WATER RESOURCES DEPT.  
SALEM, OREGON

Form Version:

MONITORING WELL REPORT - Map with location identified must be attached and shall include an approximate scale and north arrow

MULT 111765

12/17/2012

## Map of Hole








START CARD # 1049153

From	To	Description	Amount	Units

11/16/2020

## Map of Hole



## ***Appendix B***

---

### **Sampling and Analysis Plan**

### **1.0 Introduction**

This appendix presents the field and sampling procedures and the analytical testing program that will be used to complete the field and analytical work for this project. Quality assurance and quality control (QA/QC) procedures are also discussed in this appendix.

### **2.0 Field and Sampling Procedures**

The project scope of work includes collection and chemical analysis of groundwater and soil related to the investigation of the Former Fire Stations at the Portland International Airport (PDX). Data will be used to evaluate current conditions of per- and polyfluoroalkyl substances (PFAS; a component of aqueous film forming foam [AFFF]). The field and sampling procedures include the following:

- Preparatory activities;
- Soil logging and installation of two overbank deposit (OD) groundwater wells via direct push drilling methods;
- Soil logging and installation of two Columbia River sand aquifer (CRSA) groundwater wells via sonic drilling methods;
- Soil logging and installation of four temporary borings via direct push drilling methods;
- Collection of soil samples;
- Groundwater elevation measurements;
- Collection of groundwater samples from monitoring wells;
- Sample management (i.e., containers, storage, and shipment);
- Decontamination procedures; and
- Handling of investigation-derived waste (IDW).

#### **2.1 Preparatory Activities**

**Site Health and Safety Plan.** A Site-specific health and safety plan (HASP) has been prepared for the proposed activities. The HASP was prepared in general accordance with the Occupational Safety and Health Administration (OSHA) and the Oregon Administrative Rules (OAR). A copy of the HASP will be maintained at the Site during the field activities. Prior to performing any on-site work, Apex will prepare a job safety analysis (JSA) and HASP guiding Site- and project-specific activities, risks, and safety protocols. All field staff and subcontractor personnel supporting the project will be required to review and agree to abide by the HASP.



## ***Appendix B – Sampling and Analysis Plan***

---

Safety topics will be refreshed daily with the field crew using a daily tailgate safety meeting, to be conducted by Apex's Site Supervisor or Site Safety Officer.

**Property Access.** Apex will provide notification to Port personnel and Port Operations (OPS). The notification will be submitted to OPS a minimum of one week in advance and include the following:

- Port project manager contact information;
- Apex project manager and field staff contact information;
- Summary of field work;
- Site plan showing work locations;
- Ingress and egress locations for Apex; and
- Work schedule.

Airside OPS will be notified of arrival and departure (Airfield-1 phone is 503-460-4134).

**Flagging/Barricading.** Portions of the work may be performed within active aircraft operations areas. Work areas and timing will be coordinated with Airside OPS and the Port. Work areas will be designated with cones and vehicles with amber flashing beacons or as required by Airside OPS. Airside OPS will be notified of arrival and departure.

**Underground Utility Location.** Apex's project manager or designee will mobilize to the Site to mark out the proposed sampling locations with marking paint to enable the identification of nearby underground utilities by Dig-Alert/Underground Service Alert (USA). Because Dig-Alert does not mark out underground utilities on private property and because the drilling activities will be performed inside the boundaries of the Site, Port personnel will conduct an underground utility locate to mark out underground utilities located within the proximity of each proposed sampling location prior to performing the subsurface work.

If any underground utilities are identified within 5 feet of the proposed sampling location, Apex will adjust the proposed sampling location before drilling commences. Apex will also adjust the proposed drilling location to provide a safety buffer for buildings, heavy traffic areas, overhead utilities, and similar Site features so that sampling can be performed safely and with minimal disruption to existing businesses.

As an additional safety measure, all borings will be hand-cleared using a hand auger, air-knife, or post hole digger.

### **2.2 Groundwater Monitoring Well Installation**

**OD Well Installation.** Two groundwater monitoring wells will be installed using a Geoprobe direct push drill rig to an approximate depth of 15 to 20 feet bgs (Figure 6) based on recent and historical groundwater levels. They will be located west and northeast of the Former Fire Stations.

The OD monitoring wells will be installed and constructed of 2-inch diameter, Schedule 40 polyvinyl chloride (PVC) casing with 10 feet of Schedule 40 0.010-inch slot PVC screen. A clean 20/30 silica sand filter pack will be placed between the boring wall and the PVC screen and riser from the bottom of the well to approximately 1 to 2 feet above the screened interval. A bentonite seal will be placed above the sand filter pack to within approximately 1 to 2 feet of the ground surface. The bentonite seal will be placed through a side-discharge Tremie pipe to ensure positive placement without bridging or wash-out of previously placed annular materials. The seal will displace standing fluid in the zone being sealed and will be set without being diluted by groundwater. The surface will be completed with a traffic-rated flush-mounted concrete well pad and monument. A watertight locking cap and lock will secure the wellhead, and tamper-resistant bolts will secure the monument cover.

**CRSA Well Installation.** Two CRSA groundwater monitoring wells will be installed using a sonic rig to an approximate depth of 80-100 feet bgs, though the final depth will be determined based on actual lithological conditions (Figure 3). Sonic drilling will be conducted using an inner 4-inch diameter casing followed by an outer 6-inch diameter casing that sleeves over the inner casing. Sonic drilling technology combines harmonics (vibration) and rotation as the basis for tool advancement and reduces the volume of IDW created. The sonic drilling technique will also substantially reduce or eliminate communication between strata of different elevations. The inner core barrel will be advanced 10 feet into the subsurface followed by the outer casing. The core barrel will then be removed from the borehole, and the soil will be logged and sampled. Then the core barrel will be returned to the encased borehole and pushed another 10 feet. An additional 10-foot length of casing will be added to the outer casing and advanced to meet the bottom of the core barrel. This process will continue until the total depth is reached.

The CRSA monitoring wells will be installed and constructed of 2-inch diameter, Schedule 40 PVC casing with 10 feet of Schedule 40 PVC screen with 0.010-inch slots. A clean 20/30 silica sand pack will be placed between the boring wall and the PVC screen and riser from the bottom of the well to approximately 1 to 2 feet above the screened interval. A bentonite seal will be placed above the sand pack to within approximately 1 to 2 feet of the ground surface. The bentonite seal will be placed through a side-discharge Tremie pipe to ensure positive placement without bridging or wash-out of previously placed annular materials. The seal will displace standing fluid in the zone being sealed and set up without being diluted by formation water. The surface will be completed with a traffic-rated flush-mounted concrete well pad and monument. A watertight locking cap and lock will secure the wellhead, and tamper-resistant bolts will secure the monument cover.

## ***Appendix B – Sampling and Analysis Plan***

---

**Lithologic Descriptions.** Soil sampling for lithologic descriptions will be conducted for the full length of the borings for OD and CRSA wells. Soil cores will be screened for volatile organic compounds using a photoionization detector (PID), and lithologic descriptions will be made in general accordance with American Society for Testing Materials Standard 2487/2488. If adding water to a boring becomes necessary to prevent or minimize sand heaving during well installation, significantly more water will be removed during well development to confirm removal of added water prior to groundwater sampling. This will ensure collected samples are representative of subsurface conditions.

**Documentation.** The field geologist will document the well installation and construction activities. Details to be noted include the following:

- Length of well components;
- Measurements of bentonite, sand, and concrete depths;
- Types, brands, weights, and amounts of materials used;
- Documentation of decontamination; and
- Any deviation from standard procedures or problems encountered during the well installation activities.

The drilling contractor will be responsible for conforming to all applicable regulations pertaining to well construction.

### **2.3 Monitoring Well Development**

The OD and CRSA wells will be developed to establish a connection with the aquifer. Well development will occur approximately 24 hours after well installation is completed. The wells will be developed by surging and purging a minimum of five casing volumes of water from the well using a downhole pump. Field parameters will be collected during development and include temperature, pH, ORP, DO, and conductivity. Development will be considered complete when the water is visually clear and field parameters have stabilized to within 5 percent of the previous measurement for three consecutive borehole volumes. Purge water will be drummed and handled in accordance with Section 2.6. The top of inner well casing elevation, as well as the x and y location coordinates for the newly-installed wells, will also be recorded by an Oregon licensed surveyor following well installation activities.

### **2.4 Temporary Borings**

Four temporary borings will be completed to an approximate depth of 8 to 13 feet below ground surface (bgs; or to the depth needed to allow the collection of a grab groundwater sample using direct push drilling techniques). Soil and groundwater samples will be collected during the completion of each exploration. Apex staff will complete the field screening from the center of each 2.5 feet of linear core in accordance with

## ***Appendix B – Sampling and Analysis Plan***

---

Standard Operating Procedures (SOP) 2.1. Grab groundwater sampling will be completed in accordance with SOP 2.4 using a purpose-specific temporary well screen attached to the push-probe drilling equipment.

Following the completion of sampling, each exploration will be backfilled with hydrated bentonite and surfaced to match the existing grade.

### **2.5 Soil Sampling**

Samples will be collected from distinct areas of the Site to assist in soil management during future work. The three distinct areas are north, south, and west of the Former Fire Stations. Soil from well MW-101 will be used to assess the north. Soil from the four temporary borings (near previous boring B-4 on Figure 6) will be composited together to assess the south. Soil from MW-102, DW-101, and DW-102 will be composited together to assess the west. A sample will be collected from both the saturated and unsaturated zone at each area. This will be a total of six soil samples.

Based on previously installed wells and borings, the unsaturated zone is expected to be from the ground surface to 8 ft bgs north of the Former Fire Stations, 3 feet bgs near boring B-4, and 4 feet bgs to the west.

Soil samples will be collected in accordance with SOP 2.4. Composite samples will be combined by homogenizing an equal amount of soil from each boring in a stainless-steel bowl.

### **2.6 Groundwater Elevation Measurements**

Water level measurements will be collected in general accordance with SOP 2.16 for water level measurement procedures, provided in this appendix. These measurements will be collected from existing OD and Upper CRSA wells. Well covers and well caps will be opened, and the water level will be allowed to equilibrate under atmospheric conditions for at least five minutes before water level measurements are taken. Depth to water, depth to product, and/or presence of sheen will be recorded in the field notes. Noticeable odors, damage to wells, or other conditions will also be documented in the field notes.

### **2.7 Collection of Monitoring Well Samples**

Apex will collect groundwater samples from monitoring wells in accordance with the low-flow sampling techniques described in SOP 2.5, included in this appendix. Water level monitoring will be attempted during sampling, and pumping drawdown will be restricted to less than 0.3 feet. Groundwater samples collected from OD wells and Upper CRSA wells will be analyzed for PFAS by US Environmental Protection Agency (EPA) Method 1663.

Groundwater samples will be collected using dedicated PFAS-free tubing (e.g., high-density polyethylene [HDPE]) and a peristaltic pump. Existing Site monitoring wells typically include a 10-foot screen interval.



## ***Appendix B – Sampling and Analysis Plan***

---

During sample collection, the tubing will be placed in the middle of the screened interval. Groundwater will be purged prior to sampling. During purging, groundwater field parameters (pH, oxidation-reduction potential [ORP], dissolved oxygen [DO], specific conductivity, and temperature) will be measured using a flow cell connected to the discharge tubing of the sample pump. Turbidity of the water will be monitored visually with color and clarity being recorded on the sampling data sheet. Purging will be considered complete when the water quality parameters have stabilized to within 10 percent and the water is visually clear for three consecutive three-minute intervals. Sample containers will be provided by the laboratory ready for sample collection. Table B-1 lists sample container requirements.

### **2.8 Sample Management**

**Cross-Contamination.** To avoid PFAS contamination of the soil and groundwater samples, sampling personnel will avoid using items containing polytetrafluoroethylene (PTFE, also known as Teflon), low-density polyethylene (LDPE), or polypropylene as well as other items that contain PFAS, such as aluminum foil, Post-It notes, waterproof field books, markers, chemical ice packs (e.g. blue ice), certain decontamination soaps, and certain product packaging (e.g. such as that found on pre-wrapped foods and snacks). Similarly, many clothing items contain PFAS, such as those coated with Teflon or incorporating a Gore-Tex membrane. Clothing items will only be worn if they have been washed at least six times, and known PFAS-containing products will be avoided during sample collection. Field personnel will avoid the use of cosmetics, moisturizers, and hand cream. Insect repellent and sunscreen will be avoided, and alternative skin barriers (e.g., long sleeve clothing, wide-brimmed hats, etc.) will be used. PFAS contamination prevention protocols will be reviewed with personnel daily during the field activities. Before any samples are collected, the sample handler will wash their hands and wear nitrile gloves while collecting and sealing sample containers.

**Containers.** Clean sample containers will be provided by the analytical laboratory ready for sample collection (container requirements are listed in Table B-1). For samples collected for PFAS analysis, sample containers (including lids) will be HDPE or polypropylene and will not contain PTFE (Teflon).

**Labeling Requirements.** A sample label will be affixed to each sample container before sample collection. Containers will be marked with the project name, sample I.D. (unique I.D. for each sample location), date and time stamp (military time) of collection, sampler's initials, and the type of analysis.

**Sample Storage and Shipment.** Water samples will be stored in a cooler chilled with ice to below six degrees Celsius (°C). The cooler lid will be sealed with chain-of-custody seals. Samples will be sent via overnight courier to the analytical laboratory for chemical analysis. Chain-of-custody will be maintained and documented at all times.

## **Appendix B – Sampling and Analysis Plan**

---

### **2.9 Decontamination Procedures**

**Personnel Decontamination.** Personnel decontamination procedures depend on the level of protection specified for a given activity. The HASP identifies the appropriate level of protection for the type of work and expected field conditions associated with this project. In general, clothing and other protective equipment can be removed from the investigation area. Field personnel will thoroughly wash their hands and faces at the end of each day and before taking any work breaks.

**Sampling Equipment Decontamination.** To prevent cross-contamination between samples, clean, dedicated sampling equipment (e.g., groundwater sampling tubing) will be used for each sample and will be discarded after use. Cleaning of non-disposable items (i.e., field meter, telescoping swing sampler, and water level probe) will consist of washing in a detergent (Alconox®) solution, rinsing with tap water, and rinsing with de-ionized (DI; laboratory-supplied and certified PFAS-free) water. Decontamination water will be collected and handled in accordance with Section 2.6.

### **2.10 Handling of Investigation-Derived Waste**

IDW will consist of purge water, soil, decontamination water, and recoverable separate-phase petroleum hydrocarbons (SPH). Purge and decontamination IDW water will be land applied within the capped area of the current Fire Training Facility. The IDW water will not be discharged to the fire training pit if it contains sediment or SPH. Soil and recoverable SPH will be placed in properly labeled Oregon Department of Transportation-approved drums. The SPH drum will be transferred to the designated PDX IDW storage area pending receipt of chemical data. Sampling materials and personal protective equipment will be disposed of as solid waste.

## **3.0 Analytical Testing Program**

Analytical laboratory QA/QC procedures are discussed in Section 5 of this appendix.

Tables B-1 through B-3 provide the proposed analytical method, the laboratory reporting limits, and the anticipated number of samples to be collected. Samples will be collected and handled using methods described in Section 2 of this appendix. Specific container and storage requirements for samples will be discussed with the analytical laboratory prior to sample collection and will be in accordance with the container requirements presented in Table B-1.

The contaminants of interest (COI) for this project are PFAS by EPA Method 1663 which utilizes isotope dilution and solid phase extraction. Reported PFAS will include the method list of 40 compounds (see Table B-2). Soil samples will be analyzed for Total Petroleum Hydrocarbons as Diesel (TPH-d) by Method NWTPH-Dx if there are positive results for field screening (high PID readings, sheen, or free product).

### **4.0 Field Quality Assurance Program**

Table B-3 provides a summary of anticipated field QA/QC samples.

**Field Chain-of-Custody.** A chain-of-custody form will be used to record possession of a sample and to document analyses requested. Each time the sample bottles or samples are transferred between individuals, both the sender and receiver will sign and date the chain-of-custody form. When a sample shipment is transported to the laboratory, a copy of the chain-of-custody form will be included in the transport container (e.g. ice chest).

**Field Duplicate Samples.** One groundwater field duplicate sample will be collected to achieve a 10 percent ratio of duplicate to primary samples. The duplicate sample will be analyzed for PFAS. A field duplicate consists of two samples collected sequentially from one sample location to assess data variability. The field duplicate will be analyzed by the same analytical methods used for primary samples. Relative percent difference (RPD) for the field duplicate will be calculated to assess the data precision and accuracy as well as the potential variability caused by sample handling.

**Equipment Rinse Blanks.** An equipment blank will be collected and analyzed for PFAS compounds along with the field samples. The blank will be collected using laboratory-supplied and verified PFAS-free water. An equipment blank is analyzed to determine the success of equipment decontamination and can also show laboratory sources of contamination.

### **5.0 Quality Assurance Plan**

The purpose of the Quality Assurance Plan (QAP) is to specify procedures and methods for office and field documentation, sample handling and custody, recordkeeping, equipment handling, and laboratory analyses that will be used during sampling and analysis.

#### **5.1 Quality Assurance Objectives for Data Management**

The general QA objectives for this project are to develop and implement procedures for obtaining and evaluating data of acceptable quality. To collect such information, analytical data must have an appropriate degree of accuracy and reproducibility, samples collected must be representative of actual field conditions, and samples must be collected and analyzed using unbroken chain-of-custody procedures.

Specific QA objectives are as follows.

1. Establish sampling techniques that will produce analytical data representative of the media being measured.



## ***Appendix B – Sampling and Analysis Plan***

---

2. Collect and analyze a sufficient number of field duplicate samples to establish sampling precision. Laboratory duplicates of the same sample will provide a measure of precision within the sample (sample homogeneity).
3. Analyze a sufficient number of analytical duplicate samples to assess the performance of the analytical laboratory.
4. Analyze a sufficient number of blank, standard, duplicate, spiked, and check samples within the laboratory to evaluate results against numerical QA goals established for precision and accuracy.

Precision, accuracy, representativeness, completeness, and comparability parameters used to indicate data quality are defined below.

### ***5.1.1 Precision***

Precision is a measure of the reproducibility of data under a given set of conditions. Specifically, it is a quantitative measure of the variability of a group of measurements compared to their average value. For duplicate measurements, precision can be expressed as the RPD. Analysis of field duplicate samples will serve to measure the precision of sampling. Laboratory duplicate measurements will be carried out with at least a 5 percent frequency for each sample matrix.

### ***5.1.2 Accuracy***

Accuracy is the measure of error between the reported test results and the true sample concentration. True sample concentration is never known due to analytical limitations and error. Consequently, accuracy is inferred from the recovery data from spiked samples.

Because of difficulties with spiking samples in the field, the laboratory will spike samples. The laboratory will perform sufficient spike samples of a similar matrix (water or soil) to allow the computation of the accuracy.

Perfect accuracy is a 100 percent recovery.

### ***5.1.3 Representativeness***

Representativeness is a measure of how closely the results reflect the actual concentration of the chemical parameters in the medium sampled.

Sampling procedures, as well as sample-handling protocols for storage, preservation, and transportation, are designed to preserve the representativeness of the samples collected. Proper documentation will confirm that protocols are followed. This helps to assure the sample identification and integrity.



## ***Appendix B – Sampling and Analysis Plan***

---

Laboratory method blanks will be run in accordance with established laboratory protocols.

### ***5.1.4 Completeness***

Completeness is defined as the percentage of measurements made which are judged to be valid measurements. The completeness goal is essentially that a sufficient amount of valid data be generated to allow for the evaluation of site cleanup.

### ***5.1.5 Comparability***

Comparability is a qualitative parameter expressing the confidence with which one data set can be compared with another. The objective of this QAP is to assure that data developed during the sampling are comparable to other data from projects with the same media and sampling techniques. Comparability of the data will be assured by using EPA-defined procedures which specify sample collection, handling, and analytical methods.

### ***5.1.6 Documentation***

EPA Level III documentation will be generated during sampling/analysis. This level of documentation is generally considered legally defensible and consists of the following:

- Chain-of-custody;
- Holding times;
- Laboratory method blank data;
- Sample data;
- Shipping receipts;
- Laboratory notes;
- Raw data validation;
- Matrix/surrogate spike data; and
- Duplicate sample data.

## **5.2 Sampling Protocols**

### ***5.2.1 Methods***

Sampling methods are presented in Section 2. These procedures are designed to ensure that:

- Samples collected are consistent with project objectives; and

## ***Appendix B – Sampling and Analysis Plan***

---

- Samples are identified, handled, and transported in a manner that does not alter the representativeness of the data from the actual site conditions.

QA objectives for sample collection will be accomplished by a combination of the following items.

- **Standardized Procedures.** Standardized procedures will be followed and documented.
- **Laboratory QA.** Laboratory duplicate measurements will be carried out on at least 5 percent of laboratory samples. Analytical procedures will be evaluated using the protocols of the analytical laboratory. These protocols can be submitted upon request.
- **Chain-of-Custody.** Procedures for chain-of-custody are described in Section 5.3.

### **5.3 Sample and Document Custody Procedures**

The various methods used to document field sample collection and laboratory operation are presented below.

#### ***5.3.1 Field Chain-of-Custody Procedures***

Sample chain-of-custody refers to the process of tracking the possession of a sample from the time it is collected in the field through the laboratory analysis. A sample is considered to be under a person's custody if:

- It is in a person's physical possession;
- It is in view of the person after possession has been taken; or
- It is secured by that person so that no one can tamper with the sample or secured by that person in an area which is restricted to authorized personnel.

A chain-of-custody form is used to record possession of a sample and to document analyses requested. Each time the sample bottles or samples are transferred between individuals, both the sender and receiver will sign and date the chain of custody form. When a sample shipment is transported to the laboratory, a copy of the chain of custody form will be included in the transport container (i.e. ice chest).

The chain-of-custody forms are used to record the following information:

- Sample identification number;
- Sample collector's signature;
- Date and time of collection;
- Description of sample;
- Analyses requested;
- Shipper's name and address;

## ***Appendix B – Sampling and Analysis Plan***

---

- Receiver's name and address; and
- Signatures of persons involved in chain-of-custody.

Procedures for the handling, documenting, and shipping of samples are described in Section 2.

### ***5.3.2 Laboratory Operations***

The analytical laboratory has a system in place for documenting the following laboratory information:

- Calibration procedures;
- Analytical procedures;
- Computational procedures;
- Quality control procedures;
- Bench data;
- Operating procedures or any changes to these procedures; and
- Laboratory notebook policy.

Laboratory chain-of-custody procedures provide the following:

- Identification of the responsible party (sample custodian) authorized to sign for incoming field samples;
- A log consisting of sequential lab-tracking numbers; and
- Specification of laboratory sample custody procedures for sample handling, storage, and internal distribution for analysis.

### ***5.3.3 Corrections to Documentation***

Original data are recorded in field notes and on chain-of-custody forms using indelible ink. Documents will be retained even if they are illegible or contain inaccuracies that require correction.

If an error is made on a document, the individual making the entry will correct the document by crossing a line through the error, entering the correct information, and initialing and dating the correction. Any subsequent error discovered on a document is corrected, initialed, and dated by the person who made the entry.

## ***Appendix B – Sampling and Analysis Plan***

---

### **5.4 Equipment Calibration Procedures and Frequency**

Instruments and equipment used during this project will be operated, calibrated, and maintained according to the manufacturer's guidelines and recommendations. Operation, calibration, and maintenance will be performed by laboratory personnel fully trained in these procedures.

For PFAS analysis, the instrumentation will be tuned once per week and calibrated with a minimum of five standards resulting in a linear calibration ( $r^2 > 0.985$ ). A second source check standard will be analyzed with every batch and must be  $\pm 15$  percent of the average response of the mid-point calibration standard. Sample concentrations should be within bracketing calibration standards. If not, samples must be diluted to be within the calibration range.

### **5.5 Analytical Procedures**

Samples will be analyzed using SW 846 analytical protocols and EPA methodology.

Analytical instrumentation used for quantitation of PFAS must be free of PTFE transfer lines and frits to avoid elevated background levels. Only polypropylene containers will be used in the sample, standard, and extraction procedures due to potential adsorption of analytes onto glass. Laboratory reagent blanks (LRB) will be used to monitor interferences and should be less than one-third the minimum reporting limit (MRL) for each method analyte.

The limit of detection (LOD) for PFAS will be defined using the method blank and is three times the peak-to-peak amplitude of the baseline noise near the target peak. The limit of quantitation (LOQ), or MRL, is defined as five times the LOD for a specific analyte and is the lowest point of calibration. The LOD and LOQ are determined semiannually.

High-quality PFAS standards will be used to quantitate both branched and linear isomers. Documentation of these standards will be available from the analytical laboratory upon request.

### **5.6 Data Reduction, Validation, and Reporting**

Reports generated in the field and laboratory will be included with project reports.

The project manager will assure the validation of the analytical data. The laboratory generating analytical data for this project will be required to submit results that are supported by sufficient backup and QA/QC data to enable the reviewer to determine the quality of the data. The validity of the laboratory data will be determined based on the objectives outlined in Section 5.1 and Section 5.8. Data validity will also be determined based on the sampling procedures and documentation outlined in Sections 5.2 and 5.3. Upon completion of the review, the Project Manager will be responsible for assuring the development of a QA/QC

## **Appendix B – Sampling and Analysis Plan**

---

report on the analytical data. Data will be stored and maintained according to the standard procedures of the laboratory. The method of data reduction will be described in the final report.

### **5.7 Performance Audits**

Performance audits are an integral part of an analytical laboratory's standard operating procedures and are available upon request.

### **5.8 Data Measurement Assessment Procedures**

The quality of the data will be assessed based on precision, accuracy, and completeness. Procedures to compute each are discussed below.

#### **5.8.1 Precision**

The RPD is used to assess the precision of the analytical method and is calculated using the following equation:

$$(1) \quad RPD = \frac{X_s - X_d}{\frac{(X_s + X_d)}{2}} \times 100\%$$

where:

$X_s$  = analytical result of the sample

$X_d$  = analytical result of the duplicate sample

#### **5.8.2 Accuracy**

The accuracy of the data set is determined from the analysis of spiked samples. The accuracy is calculated using the following equation.

$$(2) \quad A = \frac{(X_{ss} - X_s)}{T} \times 100\%$$

where:

$A$  = accuracy

$X_{ss}$  = analytical result obtained from the spiked sample

$X_s$  = analytical result obtained from the sample

$T$  = true value of the added spike

The overall accuracy is the arithmetic mean of the spiked samples.

## ***Appendix B – Sampling and Analysis Plan***

---

### **5.8.3 Completeness**

Completeness (percent complete) of the data is determined by the following equation.

$$(3) \quad PC = \frac{\text{Number of samples with acceptable data}}{\text{Number of samples collected}} \times 100\%$$

### **5.9 Corrective Actions**

If the quality control audit detects unacceptable conditions or data, the project manager will be responsible for developing and initiating corrective action. Corrective action may include the following:

- Reanalyzing the samples, if holding time criteria permit;
- Resampling and analyzing;
- Evaluating and amending sampling and analytical procedures; and
- Accepting data and acknowledging the level of uncertainty or inaccuracy by flagging the data.

### **5.10 Quality Assurance Reports**

A quality assurance review will be conducted that presents a QA/QC evaluation of the data collected during the sampling activities for inclusion in the final report. In addition to an opinion regarding the validity of the data, the QA/QC evaluation will address the following:

- Any adverse conditions or deviations from the Sampling and Analysis Plan;
- Assessment of analytical data for precision, accuracy, and completeness;
- Significant QA problems and recommended solutions; and
- Corrective actions taken for any problems previously identified.

**Table B-1**  
**Analytical Methods - Sample Container Requirements**  
**Former Fire Stations**  
**Port of Portland**

Analyte and Method	Lab	Matrix	Container	Preservative	Storage Temperature	Holding Time	
						Sampling to Preparation	Preparation to Analysis
PFAS by EPA Method 1663	Enthalpy Analytical	Groundwater	2 x 500 mL HDPE	None	4±2°C	28 days	28 days
TPH-D by NWTPH-Dx		Soil	1 x 6 ounce HDPE			14 days	14 days
		Soil	1 x 8 ounce glass jar				

**Notes:**

1. PFAS = Per-and polyfluoroalkyl substances.
2. HDPE containers for PFAS analysis must be PFAS-free and not have Teflon-lined lids.
3. TPH-D = Total Petroleum Hydrocarbons as Diesel
4. HCl = Hydrochloric Acid
5. mL = Milliliter.
6. °C = Degrees Celsius.

Table B-2

**Analytical Methods, Anticipated Sample Number, and Laboratory Reporting Limit**  
**Former Fire Stations**  
**Port of Portland**

Analyte	Acronym	Method	Groundwater		Soil	
			Anticipated Number of Samples/Event	Laboratory Reporting Limit (ng/L)	Anticipated Number of Samples/Event	Laboratory Reporting Limit (ng/g)
Perfluorobutanoic acid	PFBA	EPA Method 1663	12	6.40	7	0.5
Perfluoro-3-methoxypropanoic acid	PFMPA	EPA Method 1663	12	3.20	7	0.5
3-Perfluoropropyl Propanoic acid	3:3 FTCA	EPA Method 1663	12	8.00	7	15
Perfluoropentanoic acid	PFPaA	EPA Method 1663	12	3.20	7	0.5
Perfluoro(4-methoxybutanoic) acid	PFMBA	EPA Method 1663	12	3.20	7	0.5
Fluorotelomer sulfonate	4:2 FTS	EPA Method 1663	12	6.00	7	0.5
Nonafluoro-3,6-dioxaheptanoic acid	NFDHA	EPA Method 1663	12	3.20	7	0.5
Perfluorobutane sulfonic acid	PFBS	EPA Method 1663	12	1.42	7	0.5
Perfluorohexanoic acid	PFHxA	EPA Method 1663	12	1.60	7	0.5
Hexafluoropropylene oxide-dimer acid (GenX)	HFPO-DA	EPA Method 1663	12	6.68	7	0.5
5:3 Fluorotelomer carboxylic acid	5:3 FTCA	EPA Method 1663	12	40.0	7	15
Perfluoro(2-ethoxyethane)sulphonic acid	PFEESA	EPA Method 1663	12	2.85	7	0.5
Perfluoroheptanoic acid	PFHpA	EPA Method 1663	12	1.60	7	0.5
Perfluoropentane sulfonic acid	PFPaS	EPA Method 1663	12	1.50	7	0.5
4,8-Dioxa-3H-perfluorononanoate	ADONA	EPA Method 1663	12	6.32	7	0.5
Fluorotelomer sulfonate	6:2 FTS	EPA Method 1663	12	6.07	7	0.5
Perfluorooctanoic acid	PFOA	EPA Method 1663	12	2.00	7	0.5
Perfluorohexane sulfonic acid	PFHxS	EPA Method 1663	12	1.60	7	0.5
7:3 Fluorotelomer carboxylic acid	7:3 FTCA	EPA Method 1663	12	40.0	7	15
Perfluorononanoic acid	PFNA	EPA Method 1663	12	1.60	7	0.5
Perfluoroheptane sulfonic acid	PFHpS	EPA Method 1663	12	1.52	7	0.5
Fluorotelomer sulfonate	8:2 FTS	EPA Method 1663	12	6.14	7	0.5
Perfluorodecanoic acid	PFDA	EPA Method 1663	12	1.60	7	0.5
Methyl perfluorooctanesulfonamidoacetic acid	MeFOSAA	EPA Method 1663	12	1.60	7	0.5
Perfluorooctane sulfonic acid	PFOS	EPA Method 1663	12	1.49	7	0.5
Ethyl perfluorooctanesulfonamidoacetic acid	EtFOSAA	EPA Method 1663	12	1.60	7	0.5
Perfluoroundecanoic acid	PFUnA	EPA Method 1663	12	1.60	7	0.5
9-Chlorohexadecafluoro-3-oxanone-1-sulfonic acid	9CI-PF3ONS	EPA Method 1663	12	6.24	7	0.5
Perfluorononane sulfonic acid	PFNS	EPA Method 1663	12	1.54	7	0.5
Perfluorooctane sulfonamide	PFOSA	EPA Method 1663	12	1.60	7	0.5
Perfluorododecanoic acid	PFDoA	EPA Method 1663	12	1.60	7	0.5
Perfluorodecane sulfonic acid	PFDS	EPA Method 1663	12	1.54	7	0.5
Perfluorotridecanoic acid	PFTrDA	EPA Method 1663	12	1.60	7	0.5
11-Chloroeicosafluoro-3-oxaundecane-1-sulfonic acid	11CI-PF3OUdS	EPA Method 1663	12	6.00	7	0.5
Perfluorotetradecanoic acid	PFTeDA	EPA Method 1663	12	1.60	7	0.5
Perfluorodecane Sulfonic Acid	PFDoS	EPA Method 1663	12	1.55	7	0.5
Methylperfluorooctanesulfonamidoethanol	MeFOSE	EPA Method 1663	12	16.0	7	0.5
Methylperfluorooctanesulfonamide	MeFOSA	EPA Method 1663	12	1.60	7	0.5
Ethyl perfluorooctane sulfonamido ethanol	EtFOSE	EPA Method 1663	12	16.0	7	0.5
Ethylperfluorooctanesulfonamide	EtFOSA	EPA Method 1663	12	1.60	7	0.5
Disel/Oil-Range Hydrocarbons	TPH-Dx	NWTPH-Dx	--	--	1	1,330

**Notes:**

ng/L = nanograms per Liter

ng/g = nanograms per gram

EPA = US Environmental Protection Agency



**Table B-3**  
**Quality Assurance Samples**  
**Former Fire Stations**  
**Port of Portland**

QA Sample Matrix	QA Sample Type	Analyses Requested	Anticipated Number of Samples
Groundwater	Field Duplicate	PFAS	1
	Equipment Blank	PFAS	1

**Notes:**

1. QA = Quality assurance.
2. PFAS = Per- and polyfluoroalkyl substances.
3. QA samples are per groundwater sampling event.

## **Apex Standard Operating Procedures**

**SOP 2.1 Standard Field Screening Procedures**

**SOP 2.4 Push-Probe Exploration Procedures**

**SOP 2.5 – Low Flow Groundwater Sampling Procedures for PFAS**

**SOP 2.16 – Water Level Measurement Procedures**

## 1. PURPOSE AND SCOPE

This Standard Operating Procedure (SOP) provides instructions for standard field screening. Field screening results are used to aid in the selection of soil samples for chemical analysis. This procedure is applicable during Apex Companies, LLC (Apex) soil sampling operations.

Standard field screening techniques include the use of a photoionization detector (PID) to assess for volatile organic compounds (VOCs), for the presence of separate-phase petroleum hydrocarbons using a sheen test. These methods will not detect all potential contaminants, so selection of screening techniques shall be based on an understanding of the site history. The PID is not compound or concentration-specific, but it can provide a qualitative indication of the presence of VOCs. PID measurements are affected by other field parameters such as temperature and soil moisture. Other field screening methods, such as screening for dense non-aqueous phase liquid (DNAPL) using dye or UV light, are not considered "standard" and will be detailed in the site-specific sampling and analysis plan (SAP).

## 2. EQUIPMENT AND MATERIALS

The following materials are necessary for this procedure:

- PID with calibration gas (record daily calibration/calibration check in field notes);
- Plastic resealable bags (for PID measurement); and
- Glass jars or stainless steel bowls (for sheen testing).

## 3. METHODOLOGY

Each soil sample will be field screened for VOCs using a PID and for the presence of separate-phase petroleum hydrocarbons using a sheen test. If the presence of DNAPL is suspected, then screening using dye and UV light may also be completed. For information regarding screening using dye or UV light, refer to the site specific sampling and analysis plan.

PID lamps come in multiple sizes, typically 9.8, 10.6, and 11.7 electron volts (eV). The eV rating for the lamp must be greater than the ionization potential (in eV) of a compound in order for the PID to detect the compound. For petroleum hydrocarbons, a lamp of at least 9.8 eV should be used. For typical chlorinated alkenes (dichloroethene, trichloroethene, tetrachloroethene, or vinyl chloride.), a lamp of at least 10.6 eV should be used. The compatibility of the lamp size with the site constituents should be verified prior to the field event and will be detailed in the site-specific SAP.

**PID Calibration Procedure:** The PID used on-site should be calibrated daily or more frequently if needed. Calibration of the PID should be documented in field notes. Calibrations procedures should be conducted according to the manufacturer's instructions. .

### PID Screening Procedure:

- Place a representative portion (approximately one ounce) of freshly exposed, uncompacted soil into a clean resealable plastic bag.
- Seal the bag and break up the soil to expose vapors from the soil matrix.
- Allow the bag to sit to reach ambient temperature. Note: Ambient temperature and weather conditions/humidity should be recorded in field notes. Changes in ambient temperature and weather during the field work should also be recorded, as temperature and humidity can affect PID readings.
- Carefully insert the intake port of the PID into the plastic bag.
- Record the PID measurement in the field notes or boring logs.

### Sheen Test Procedure:

- Following the PID screen, place approximately one ounce of freshly exposed, uncompacted soil into a clean glass jar or stainless steel bowl.

**STANDARD OPERATING PROCEDURE**

SOP Number: 2.1

Date: November 9, 2009

**STANDARD FIELD SCREENING PROCEDURES**

Revision Number: 1.1

Page: 2 of 2

- Add enough water to cover the sample.
- Observe the water surface for signs of discoloration/sheen and characterize

No Sheen (NS)	No visible sheen on the water surface
Biogenic Film (BF)	Dull, platy/blocky or foamy film.
Slight Sheen (SS)	Light sheen with irregular spread, not rapid. May have small spots of color/iridescence. Majority of water surface not covered by sheen.
Moderate Sheen (MS)	Medium to heavy coverage, some color/iridescence, spread is irregular to flowing. Sheen covering a large portion of water surface.
Heavy Sheen (HS)	Heavy sheen coverage with color/iridescence, spread is rapid, entire water surface covered with sheen. Separate-phase hydrocarbons may be evident during sheen test.

## 1. PURPOSE AND SCOPE

This Standard Operating Procedure (SOP) describes the methods for observing and sampling from push-probes (i.e., GeoProbe™). Subsurface soil cores may be obtained using this system for purposes of determining subsurface soil conditions and for obtaining soil samples for physical and/or chemical evaluation. Grab groundwater samples may be collected using temporary well screens. Soil vapor samples may be obtained using temporary well points. Shallow (less than 50 feet), small-diameter (2-inch max) pre-packed wells may also be installed using push-probe equipment. This procedure is applicable during all Apex Companies, LLC (Apex) push-probe activities.

## 2. EQUIPMENT AND MATERIALS

The following materials are necessary for this procedure:

- Traffic cones, measuring tape, spatula, and buckets/drums
- Sampling equipment (water level probe, pumps, tubing) and laboratory-supplied sample containers
- Field documentation materials
- Decontamination materials
- Personal protective equipment (as required by project Health and Safety Plan)

## 3. METHODOLOGY

### Coring Procedure (Conducted by Drilling Subcontractor):

The sampling procedure includes driving a 2-inch outside-diameter, 5-foot-long, push-probe soil sampler to the desired depth using a combination of hydraulic pressure and mechanical hammer blows. When the sampling depth is reached, the pin attaching the sampler's tip is released (if a tip is used), which allows the tip to slide inside the sampler (Macro-Core Sampler with removable plastic liner). The sampler is driven the length of the sampler to collect a soil core, which is then withdrawn from the exploration. When the sampler is retrieved from the borehole the drive head/cutting shoe is detached and the liner is removed. Soil cores are collected continuously to the full depth of the exploration unless otherwise specified in a project-specific sampling and analysis plan (SAP). Verify that the subcontractor decontaminates the sampling device (per SOP 1.2) prior to its initial use and following collection of each soil sample.

### Logging and Soil Sample Collection:

Remove the soil core from the sampler for field screening, description, and placement into sample jars. Soil samples will be collected for field screening and possible chemical analysis on two foot intervals unless otherwise specified in a project-specific SAP. The sampling interval will be determined in the field based on recovery, soil variability, and evidence of contamination. Complete field screening as specified in SOP-2.1. Soil samples should be collected using different procedures for volatile on non-volatile analyses, as follows.

- **Volatile Analyses.** Sampling for volatile organics analysis (VOA) is different than other routine physical or chemical testing because of the potential loss of volatiles during sampling. To limit volatile loss, the soil sample must be obtained as quickly and as directly as possible. If a VOA sample is to be collected as part of a multiple analyte sample, the VOA sample portion will be obtained first. The VOA sample should be obtained from a discrete portion of the entire collected sample and should not be composited or homogenized. Sample bottles should be filled to capacity, with no headspace. Specific procedures for collecting VOA samples using the EPA Method 5035 are discussed in SOP 2.7.
- **Other Analyses.** Soil samples for non-volatile analyses will be thoroughly homogenized in a stainless steel bowl prior to bottling. Sample homogenizing is accomplished by manually mixing the entire soil

sample in the stainless steel bowl with a clean sampling tool until a uniform mixture is achieved. The sample jar should be filled completely.


Any extra soil generated during probing activities will be placed in Department of Transportation (DOT) approved drums.

Grab Groundwater Sample Collection:

Collect grab groundwater samples using a sampling attachment with a 4 to 5-foot-long temporary screen (specify to drillers whether to use decontaminated stainless steel or disposable PVC. Also, specify whether a filter pack is necessary based on field observations). Obtain samples using a peristaltic pump unless otherwise specified in the SAP with new tubing for each boring. Record field parameters (e.g., temperature, conductivity, and pH) prior to sampling.

Backfilling the Excavation (Conducted by Drilling Subcontractor):

After sampling activities are completed, abandon each exploration in accordance with Oregon Water Resources Department (OWRD) regulations and procedures. The abandonment procedure typically consists of filling the exploration with granular bentonite and hydrating the bentonite with water. Match the surface completion to the surrounding materials.

<b>SOP 2.5</b>	<b>Standard Operating Procedure</b>	
<b>Rev 0.05</b>	<b>Low Flow Groundwater Sampling Procedures for PFAS</b>	
<b>Page 1 of 6</b>	<b>Owner: Heather Gosack Review by: 2022</b>	<b>Issued: Feb 7, 2019 Revised: May 28, 2021</b>

## **1. Purpose**

This Standard Operating Procedure (SOP) describes the methods for collection of groundwater samples for per- and polyfluorinated alkyl substances (PFAS) from monitoring wells applying low flow protocols. Low flow sampling is a method of collecting samples that does not require the removal of large volumes of water and therefore does not overly agitate the water, suspend particles, or potentially aspirate volatile organic compounds (VOCs). Typical flow rates for low flow sampling range from 0.1 liters per minute (L/min) to 0.5 L/min depending on site characteristics. Low-flow purge methods are the preferred sampling method for PFAS based on their chemical characteristics, to ensure the most representative groundwater sample is collected. The groundwater monitoring activities will consist of measuring water levels, purging and sampling groundwater, and measuring groundwater field parameters. This procedure is applicable during Apex Companies low flow groundwater sampling activities where the analytical program includes PFAS compounds. The procedures in this SOP are consistent with low flow sampling for non-PFAS compounds and include protocols to address potential for cross-contamination from materials containing PFAS.

## **2. Scope**


This SOP applies to all Apex field events where low flow methods will be used to collect groundwater samples for analysis of PFAS.

## **3. Equipment and Materials**

The following materials are necessary for this procedure:

- Traffic cones, tools, keys, and buckets/drums.
- Water quality meter with calibration solutions (record daily calibration/calibration check in field notes).
- Sampling equipment including a PFAS-free water level probe, PFAS-free pumps, PFAS-free tubing (high-density polyethylene [HDPE] or silicone tubing), and laboratory-supplied PFAS-free (HDPE) sample containers. Sample containers should not have Teflon®-lined lids. PFAS may adsorb to glass containers; therefore, glass should be avoided for water samples.
- Field documentation materials.
- PFAS-free decontamination materials that do not contain fluorosurfactants.
- Personal protective equipment (as required by project Health and Safety Plan).




<b>SOP 2.5</b>	<b>Standard Operating Procedure</b>	
<b>Rev 0.05</b>	<b>Low Flow Groundwater Sampling Procedures for PFAS</b>	
<b>Page 2 of 6</b>	<b>Owner: Heather Gosack</b> <b>Review by: 2022</b>	<b>Issued: Feb 7, 2019</b> <b>Revised: May 28, 2021</b>

Prior to conducting the sampling event, a materials screening should be performed to identify field equipment and personal protective equipment (PPE) that are PFAS-free to reduce the risk of cross-contamination. The materials screening should include a review of safety data sheets (SDS) and ingredient lists (in personal care products, sunscreens, insect repellants, etc.). Additional details regarding which materials are allowed and which are prohibited are provided below.

The following PFAS-containing equipment and materials are PROHIBITED and should be avoided when sampling soil for PFAS:

- Teflon®-containing materials (polytetrafluoroethylene [PTFE]) (e.g. sample containers, tubing, bailers, tape, plumbing paste). In cases where Teflon®-containing materials are unavoidable, ensure adequate purging is performed prior to sampling and equipment blanks are collected prior to sampling.
- Low-density polyethylene (LDPE)-containing materials (e.g. disposable plastic storage bags, or containers used to transport samples, tubing). In cases where LDPE-containing materials are unavoidable, an equipment blank can be collected to ensure the LDPE is PFAS-free. LDPE does not typically contain PFAS in the raw materials; however, LDPE products are often cross-contaminated with PFAS during manufacturing.
- Materials containing polyvinylidene fluoride (PVDF; Kynar®), which can be found in tubing, films/coatings on aluminum, lithium-ion batteries, and wire insulators.
- Materials containing polychlorotrifluoroethylene (PCTFE; Neoflon®), which can be found on food packaging, valves, seals, and gaskets.
- Materials containing ethylene-tetrafluoroethylene (ETFE; Tefzel®), which can be found on wire insulation, pipe liners, and cable tie wraps.
- Materials containing fluorinated ethylene propylene (FEP; Teflon®; Hostaflon®; Neoflon®), which can be found in labware, wire insulation, and pipe linings.
- Paper products such as waterproof field books (e.g. Rite-in-the-Rain), plastic clipboards, binders, spiral hard cover notebooks, sticky notes, or glue materials.
- Markers.
- Chemical (blue) ice packs.
- Latex gloves.
- Coated materials, including aluminum foil.
- Decontamination soaps containing fluorosurfactants such as Decon 90.
- Water that is not verified to be “PFAS-free” by the laboratory to be used for trip, equipment, and decontamination blanks and decontamination processes.

<b>SOP 2.5</b>	<b>Standard Operating Procedure</b>	
<b>Rev 0.05</b>	<b>Low Flow Groundwater Sampling Procedures for PFAS</b>	
<b>Page 3 of 6</b>	<b>Owner: Heather Gosack</b> <b>Review by: 2022</b>	<b>Issued: Feb 7, 2019</b> <b>Revised: May 28, 2021</b>


- Water resistant, waterproof, stain-treated clothing or shoes, including Gore-Tex™ and Tyvek® materials. If PFAS-free shoes cannot be used, PFAS-free over-boots may be worn and donned in the staging area prior to sampling.

Additionally, there is documentation that some personal care products, as well as food and drinks, may introduce PFAS contaminants to the samples. Therefore, these additional precautions should be taken during the sampling event:

- Many personal care products, such as cosmetics, moisturizers, and hand creams, contain PFAS. These products should be avoided during sampling events and 24 hours prior to sampling. Please note that many products marketed as ‘natural’ or ‘organic’ contain PFAS. If personal care products must be used, the ingredient list should be checked for PFAS.
- Many manufactured sunblocks and insect repellents contain PFAS. Only PFAS-free sunblock and insect repellent should be used during sampling events. If sunscreens or insect repellants are used during a PFAS sampling event, the product(s) should be applied in the staging area. After application, hands should be washed, and new nitrile gloves used.
- Many food and drink wrappers and containers, paper plates, aluminum foil, and paper towels contain PFAS. Food containers and related items should be kept out of the sampling area. Samplers should wash hands thoroughly with PFAS-free water and soap after handling food wrappers and containers.

The following equipment and materials are typically PFAS-free and recommended for use when collecting samples for PFAS analysis:

- HDPE, polypropylene, acetate, nylon, polyvinyl chloride (PVC), cotton, stainless steel, natural rubber, and silicone materials (e.g. tubing, bailers, tape, plumbing paste).
- Nitrile gloves that are frequently changed.
- Loose paper with Masonite or aluminum clipboards.
- Bags of ice.
- Alconox® or Liquinox®.
- Laboratory-supplied and verified PFAS-free water to be used for trip, equipment, and decontamination blanks and decontamination processes.
- Cotton textiles are recommended for field clothing and should be laundered a minimum of 6 times from time of purchase due to possible PFAS-related treatments. Fabric softener must be avoided. Rain gear should be made from polyurethane, PVC, and/or wax-coated materials.

<b>SOP 2.5</b>	<b>Standard Operating Procedure</b>	
<b>Rev 0.05</b>	<b>Low Flow Groundwater Sampling Procedures for PFAS</b>	
<b>Page 4 of 6</b>	<b>Owner: Heather Gosack</b> <b>Review by: 2022</b>	<b>Issued: Feb 7, 2019</b> <b>Revised: May 28, 2021</b>

There is some documentation that field vehicles could have seats treated with stain resistant products and could represent a source of cross-contamination. If possible, cover treated vehicle seats with a well-laundered cotton blanket or sheet. Do not handle sample containers on the vehicle seats. Always change gloves after exiting the vehicle.

#### **4. Methodology**

---

##### Field Preparation:


Prior to sampling, set up separate eating, staging, and sampling areas to help avoid PFAS cross-contamination. Due to the high risk of cross-contamination, any visitors to the site should remain at a distance from the sampling area. A sequence should be set up prior to sampling. Water sample collection should start with wells suspected to be least contaminated and end with wells suspected to be most contaminated.

##### Water Levels:

Water levels in the wells will be measured and recorded for the purpose of determining groundwater elevations and gradient. The wells will be opened and the water level allowed to equilibrate before the measurements are taken. When opening monitoring wells, take precautions to prevent injury from the well-cap in the event the well is over-pressured. Measurements of the depth to water will be made to the nearest 0.01 foot using an electronic probe.

##### Purging:

Purge using low-flow sampling equipment (e.g., peristaltic pump or bladder pump) at a low-flow rate to limit water table drawdown. Unless specified otherwise in the project-specific sampling and analysis plan (SAP), the sample tubing/pump will be lowered to the middle of the saturated screened interval. To assess the effectiveness of purging, groundwater field parameters (pH, dissolved oxygen [DO], oxidation-reduction potential [ORP], electrical conductivity, and temperature) will be measured using a flow cell connected to the discharge tubing of the sample pump. Purging will generally be considered complete when the water quality parameters (i.e., pH, temperature, DO, ORP, and specific conductance) stabilize within 10 percent for three consecutive 3-minute intervals. Consult the project-specific SAP for additional parameters, stabilization criteria, and required pump depth, as these parameters may vary based on project site and local requirements and guidance. Purge water will be placed in Department of Transportation (DOT)-approved drums or ground-applied based on client preferences and/or local regulations and guidance.

<b>SOP 2.5</b>	<b>Standard Operating Procedure</b>	
<b>Rev 0.05</b>	<b>Low Flow Groundwater Sampling Procedures for PFAS</b>	
<b>Page 5 of 6</b>	<b>Owner: Heather Gosack Review by: 2022</b>	<b>Issued: Feb 7, 2019 Revised: May 28, 2021</b>

#### Sample Collection:

After the purging of each well is complete, collect groundwater samples for chemical analyses using the same pump used for the well purging. Place collected samples into cooler(s) kept at temperatures that do not exceed 6 degrees Celsius (°C). Chemical/blue ice packs should not be used to keep PFAS samples chilled. The samples and regular ice should be double bagged using bags made of non-PFAS materials.

#### Low Yield Sampling Procedure:

If drawdown of the water table is unavoidable and a well pumps dry during purging, discontinue measurement of water quality parameters. Collect groundwater samples once the water level recovers to 90 percent of the pre-purge water column. Contact project manager in the event of slow recharge conditions.

#### Decontamination Procedures:

Field sampling equipment, including water level indicators, oil/water interface meters, pumps, and other non-dedicated equipment, should be decontaminated before first use and in between sampling each well location. The SDS of detergents or soaps used for decontamination procedures should be reviewed to ensure that fluorosurfactants are not listed as ingredients. Laboratory-certified PFAS-free water should be used for the final rinse during decontamination of sampling equipment. When possible, equipment should also be rinsed with PFAS-free water immediately prior to first use. Sampling equipment can be scrubbed with a polyethylene or PVC brush as needed to remove particulates.


## **5. References**

---

California State Water Quality Control Board, Division of Water Quality, 2020. Per-and Polyfluoroalkyl Substances (PFAS) Sampling Guidelines for Non-Drinking Water. September 2020.

Massachusetts Department of Environmental Protection, 2019. Fact Sheet, Interim Guidance on Sampling and Analysis for PFAS at Disposal Sites Regulated under the Massachusetts Contingency Plan. June 19, 2018. Updated December 27, 2019.

Michigan Department of Environmental Quality, 2018. General PFAS Sampling Guidance. October 16, 2018.

<b>SOP 2.5</b>	<b>Standard Operating Procedure</b>	
<b>Rev 0.05</b>	<b>Low Flow Groundwater Sampling Procedures for PFAS</b>	
<b>Page 6 of 6</b>	<b>Owner: Heather Gosack</b> <b>Review by: 2022</b>	<b>Issued: Feb 7, 2019</b> <b>Revised: May 28, 2021</b>

New Hampshire Department of Environmental Services, 2019. Per- and Polyfluoroalkyl Substances (PFAS) Sample Collection Guidance. May 2019.

New York Department of Environmental Conservation, 2021. Sampling, Analysis, and Assessment of Per- and Polyfluoroalkyl Substances (PFAS). January 2021.

## 1. PURPOSE AND SCOPE

This Standard Operating Procedure (SOP) describes procedures for the collection of groundwater level measurements and separate phase hydrocarbon (SPH) measurements. Measurements may be collected as an independent event or in conjunction with groundwater sampling or SPH removal. This SOP is applicable for Apex Companies, LLC (Apex) sites and projects.

## 2. EQUIPMENT AND MATERIALS

The following materials are necessary for this procedure:

- Water level or oil/water interface probe (as appropriate);
- Field documentation materials;
- Decontamination materials;
- Bailers or tape/paste (to confirm unusual SPH detections) and
- Personal protective equipment (PPE; as required by project Health and Safety Plan).

## 3. METHODOLOGY

**Preparation.** Obtain and review table of well construction details and historical groundwater and SPH levels/thicknesses. Bring tables into the field for ready reference.

**Field Procedure.** Water level and SPH measurements should be collected upon arrival at the site. Appropriate PPE (as required by the project-specific Health and Safety Plan) should be worn during measurement activities. During groundwater sampling events, measurements should be collected (1) prior to, during, and after purging and sampling. Water level measurements during low-flow sampling are conducted to ensure that drawdown is not occurring during purging/sampling. Low-flow sampling methods are described in SOP 2.5. The following procedures should be followed when collecting groundwater level and SPH measurements from wells:

### No SPH in monitoring well

1. The electronic probe should be tested to ensure proper instrument response. If response is inadequate, replace batteries or repair probe as needed.
2. Well covers and caps will be opened and the water level allowed to equilibrate under atmospheric conditions. Observe for indications that water levels may not be at equilibrium such as:
  - a. Escaping air upon loosening of well cap; or
  - b. Water level above the top of the well screen.

For either of these conditions, equilibrium should be verified by repeating water level measurements over five-minute intervals until successive equal measurements are obtained. Otherwise allow water levels to equilibrate for a minimum of five minutes before measurements are taken. Unless otherwise indicated in the work scope of site-specific sampling plan, water level measurements should be taken from the least contaminated wells first to avoid cross-contamination.

3. Locate the reference point on the well riser pipe.
4. Slowly lower the probe until the probe signal indicates that water has been contacted.
5. Record the depth-to-water (DTW) probe reading at the reference point. Measurements should be collected to the nearest 0.01 foot.
6. Withdraw the probe and repeat steps 5 and 6. Measurements should agree within a precision of 0.01 feet. Repeat if needed until a precision of 0.01 feet is obtained.
7. If the work scope or site specific sampling plan requires that the depth-to-bottom (DTB) of monitoring wells is measured, then the probe should be lowered to the bottom of the well and the DTB reading at the reference point should be measured to the nearest 0.01 foot.
8. Remove probe and decontaminate the tape using alcohol wipes then wash the tape and probe in a detergent (Alconox®) solution, rinse with tap water, and a final deionized water rinse. DO NOT USE ALCOHOL WIPES ON THE PROBE TIP. Describe in field notes unusual characteristics of SPH that may bias thickness readings (e.g. unusually viscous product).

SPH in monitoring well

1. Repeat above steps 1 through 5.
2. Slowly lower the oil/water interface probe until the signal indicates that SPH has been contacted (generally a steady tone and signal light).
3. Record the depth-to-product (DTP) probe reading at the reference point. Measurements should be collected to the nearest 0.01 foot.
4. Continue lowering the probe until the signal indicates that water has been contacted (generally an intermittent tone and signal light).
5. Record the DTW probe reading at the reference point. Measurements should be collected to the nearest 0.01 foot.
6. Withdraw the probe and repeat steps 5 and 6. Measurements should agree within a precision of 0.01 feet. Repeat if needed until a precision of 0.01 feet is obtained.
7. Remove probe and initially decontaminate the tape using alcohol wipes then wash/scrub the tape and probe in a detergent (Alconox®) solution, rinse with tap water, and a final deionized water rinse. DO NOT USE ALCOHOL WIPES ON THE PROBE TIP. Describe in field notes unusual characteristics of SPH that may bias thickness readings (e.g. unusually viscous product).
8. If unusual SPH thicknesses are detected (e.g. SPH is detected in well with no prior history of SPH or thicknesses are greater than prior detections), verify presence/thickness using alternative technique (e.g. bailer, tape and water/petroleum colorimetric paste).



## ***Appendix C***

---

### **Health and Safety Plan**



## HEALTH AND SAFETY PLAN – Level 2

This Level 2 HASP is intended to provide health and safety guidelines for project field work meeting the following criteria:

- **Short-duration work not exceeding 30 consecutive days**
- **“Buddy System” in use (or communication plan implemented for “lone worker”)**
- **Some likelihood of chemical and/or physical hazard exposure**
- **Limited number of job tasks (5 or less)**
- **No supplied-air respirator use**
- **Limited number of subcontractors involved (3 or less)**

The Project Manager should review this Health and Safety Plan with all Apex project personnel. A copy of the HASP must be kept in the field with the project team as well as maintained in project files.

<b>Administrative Information</b>  This document is valid for a maximum time period of one year after initial completion and must be re-evaluated by the project team at that time.  A minimum of two persons with appropriate training and medical surveillance must be onsite or an appropriate communication plan must be implemented. A mix of Apex and other personnel can satisfy this requirement.	Site Name and Location Portland International Airport, Portland, Oregon	
	Client Contact David Breen	
	Project Name PDX Former Fire Stations	
	Health & Safety Plan Date 6/19/2024	Revision Number and Date
	Field Work Start Date TBD	Anticipated Field Work End Date TBD
	Project Manager ( <i>responsible for implementing the site health and safety program on this project</i> ) Carmen Owens	Site Safety Officer (SSO) ( <i>responsible for overall site health and safety performance on this project</i> ). Chris Weer

<b>Project Background and Scope of Work</b>  Include numbered list of tasks to be completed by Apex personnel during this project, and a separate list of tasks to be completed by any subcontractors at the site.  JSAs are to be prepared for each task listed. Subcontractors are responsible for preparing JSAs for their activities.	Apex Scope of Work: 1. Gauge groundwater monitoring wells for depth to water. 2. Sample groundwater at Site monitoring wells. 3. Oversee the installation of 2 shallow groundwater monitoring wells and 4 borings via Geoprobe. 4. Oversee the installation of 2 deep groundwater monitoring wells via Sonic Rig. 5. Collect soil samples 6. Log soil lithology and conduct field screening. 7. Develop and sample groundwater monitoring wells. 8. Sample Management/COC
	Subcontractor Scope of Work: One Call will be conducted more than 48 hours before fieldwork begins. The Port of Portland will provide private utility location services. Drilling subcontractor will operate a direct push probe unit and a sonic drill rig. As an additional safety measure, all wells will be hand-cleared using a hand auger, air-knife, or post hole digger. Holes will be cleared to 5 feet using an air-knife and vacuum truck or with hand auger.

<b>Site/Project General Information</b>  An asterisk (*) indicates that additional checklists or permits are required and must be completed and attached to this document.  A double asterisk (**) indicates that a Risk Review performed by a member of the Corporate Safety Committee must take place prior to beginning fieldwork on the project.	<b>Site Type (check all applicable boxes)</b>  <table border="0"> <tr> <td><input checked="" type="checkbox"/> Active Facility</td> <td><input type="checkbox"/> Remote Facility</td> <td><input type="checkbox"/> Inactive Facility</td> <td><input type="checkbox"/> Residential</td> </tr> <tr> <td><input type="checkbox"/> Mine</td> <td><input type="checkbox"/> Railroad</td> <td><input type="checkbox"/> Industrial</td> <td><input checked="" type="checkbox"/> Secured</td> </tr> <tr> <td><input type="checkbox"/> Uncontrolled</td> <td><input checked="" type="checkbox"/> Other (specify)</td> <td colspan="2">Active facility with multiple forms of transportation.</td> </tr> </table>	<input checked="" type="checkbox"/> Active Facility	<input type="checkbox"/> Remote Facility	<input type="checkbox"/> Inactive Facility	<input type="checkbox"/> Residential	<input type="checkbox"/> Mine	<input type="checkbox"/> Railroad	<input type="checkbox"/> Industrial	<input checked="" type="checkbox"/> Secured	<input type="checkbox"/> Uncontrolled	<input checked="" type="checkbox"/> Other (specify)	Active facility with multiple forms of transportation.																				
	<input checked="" type="checkbox"/> Active Facility	<input type="checkbox"/> Remote Facility	<input type="checkbox"/> Inactive Facility	<input type="checkbox"/> Residential																												
<input type="checkbox"/> Mine	<input type="checkbox"/> Railroad	<input type="checkbox"/> Industrial	<input checked="" type="checkbox"/> Secured																													
<input type="checkbox"/> Uncontrolled	<input checked="" type="checkbox"/> Other (specify)	Active facility with multiple forms of transportation.																														
<b>Main Site Hazards (check all applicable boxes)</b>  <table border="0"> <tr> <td><input checked="" type="checkbox"/> Slip/Trip/Fall</td> <td><input type="checkbox"/> Cold Stress</td> <td><input type="checkbox"/> Heat Stress</td> <td><input type="checkbox"/> Extreme Weather</td> </tr> <tr> <td><input checked="" type="checkbox"/> Biological</td> <td><input checked="" type="checkbox"/> Organic/Inorganic Chemicals</td> <td><input checked="" type="checkbox"/> High Noise</td> <td><input type="checkbox"/> Construction Traffic</td> </tr> <tr> <td><input checked="" type="checkbox"/> Vehicular Traffic</td> <td><input checked="" type="checkbox"/> Respirable Particles</td> <td><input type="checkbox"/> Excavations</td> <td><input checked="" type="checkbox"/> Buried/Overhead Utilities</td> </tr> <tr> <td><input type="checkbox"/> Non-Ionizing Radiation</td> <td><input checked="" type="checkbox"/> Security</td> <td><input type="checkbox"/> ASTs/USTs</td> <td><input type="checkbox"/> Manlift/Cherry Picker Use</td> </tr> <tr> <td><input type="checkbox"/> Work Over 6' High*</td> <td><input checked="" type="checkbox"/> Hand/Portable Power Tools</td> <td><input type="checkbox"/> Oxygen Deficiency</td> <td><input type="checkbox"/> Construction</td> </tr> <tr> <td><input type="checkbox"/> Blasting Agents</td> <td><input type="checkbox"/> Confined Spaces</td> <td><input type="checkbox"/> Welding or Hot Work</td> <td><input type="checkbox"/> Lockout/Tagout*</td> </tr> <tr> <td><input type="checkbox"/> Lockout/Tagout</td> <td><input type="checkbox"/> Forklift Use</td> <td><input type="checkbox"/> Chemical Mixing**</td> <td><input checked="" type="checkbox"/> Commercial Vehicle</td> </tr> <tr> <td><input type="checkbox"/> Scaffold Use</td> <td><input type="checkbox"/> Portable Ladders</td> <td><input type="checkbox"/> Other (specify)</td> <td></td> </tr> </table>	<input checked="" type="checkbox"/> Slip/Trip/Fall	<input type="checkbox"/> Cold Stress	<input type="checkbox"/> Heat Stress	<input type="checkbox"/> Extreme Weather	<input checked="" type="checkbox"/> Biological	<input checked="" type="checkbox"/> Organic/Inorganic Chemicals	<input checked="" type="checkbox"/> High Noise	<input type="checkbox"/> Construction Traffic	<input checked="" type="checkbox"/> Vehicular Traffic	<input checked="" type="checkbox"/> Respirable Particles	<input type="checkbox"/> Excavations	<input checked="" type="checkbox"/> Buried/Overhead Utilities	<input type="checkbox"/> Non-Ionizing Radiation	<input checked="" type="checkbox"/> Security	<input type="checkbox"/> ASTs/USTs	<input type="checkbox"/> Manlift/Cherry Picker Use	<input type="checkbox"/> Work Over 6' High*	<input checked="" type="checkbox"/> Hand/Portable Power Tools	<input type="checkbox"/> Oxygen Deficiency	<input type="checkbox"/> Construction	<input type="checkbox"/> Blasting Agents	<input type="checkbox"/> Confined Spaces	<input type="checkbox"/> Welding or Hot Work	<input type="checkbox"/> Lockout/Tagout*	<input type="checkbox"/> Lockout/Tagout	<input type="checkbox"/> Forklift Use	<input type="checkbox"/> Chemical Mixing**	<input checked="" type="checkbox"/> Commercial Vehicle	<input type="checkbox"/> Scaffold Use	<input type="checkbox"/> Portable Ladders	<input type="checkbox"/> Other (specify)	
<input checked="" type="checkbox"/> Slip/Trip/Fall	<input type="checkbox"/> Cold Stress	<input type="checkbox"/> Heat Stress	<input type="checkbox"/> Extreme Weather																													
<input checked="" type="checkbox"/> Biological	<input checked="" type="checkbox"/> Organic/Inorganic Chemicals	<input checked="" type="checkbox"/> High Noise	<input type="checkbox"/> Construction Traffic																													
<input checked="" type="checkbox"/> Vehicular Traffic	<input checked="" type="checkbox"/> Respirable Particles	<input type="checkbox"/> Excavations	<input checked="" type="checkbox"/> Buried/Overhead Utilities																													
<input type="checkbox"/> Non-Ionizing Radiation	<input checked="" type="checkbox"/> Security	<input type="checkbox"/> ASTs/USTs	<input type="checkbox"/> Manlift/Cherry Picker Use																													
<input type="checkbox"/> Work Over 6' High*	<input checked="" type="checkbox"/> Hand/Portable Power Tools	<input type="checkbox"/> Oxygen Deficiency	<input type="checkbox"/> Construction																													
<input type="checkbox"/> Blasting Agents	<input type="checkbox"/> Confined Spaces	<input type="checkbox"/> Welding or Hot Work	<input type="checkbox"/> Lockout/Tagout*																													
<input type="checkbox"/> Lockout/Tagout	<input type="checkbox"/> Forklift Use	<input type="checkbox"/> Chemical Mixing**	<input checked="" type="checkbox"/> Commercial Vehicle																													
<input type="checkbox"/> Scaffold Use	<input type="checkbox"/> Portable Ladders	<input type="checkbox"/> Other (specify)																														

<p><b>Chemical Products Apex will Use or Store Onsite</b></p> <p>For each chemical product identified, an SDS must be attached to this HASP</p>	<div style="display: flex; flex-wrap: wrap;"> <div style="width: 33%;"> <input checked="" type="checkbox"/> Alconox or Liquinox  <input checked="" type="checkbox"/> Hydrochloric acid (HCl)*  <input checked="" type="checkbox"/> Nitric acid (HNO<sub>3</sub>)*  <input type="checkbox"/> Sodium hydroxide (NaOH)*         </div> <div style="width: 33%;"> <input type="checkbox"/> Calibration gas (Methane)  <input type="checkbox"/> Calibration gas (Isobutylene)  <input type="checkbox"/> Calibration gas (Pentane)  <input type="checkbox"/> Calibration gas (4-gas mixture)  <input type="checkbox"/> Other (specify)         </div> <div style="width: 33%;"> <input type="checkbox"/> Isopropyl Alcohol  <input type="checkbox"/> Household bleach (NaOCl)*  <input checked="" type="checkbox"/> Sulfuric acid (H<sub>2</sub>SO<sub>4</sub>)*  <input type="checkbox"/> Hexane  <input type="checkbox"/> Other (specify)         </div> </div> <p><b>*NOTE: Eyewash solution shall be readily available on ALL projects where corrosive materials are used or stored, including sample preservatives.</b></p>
---	--

<p><b>Safe Work Practices</b></p> <p>Place a checkmark by applicable SWPs and attach to this document</p> <p>For hazards not covered by SWPs listed in this section, ensure the hazard is addressed in the JSA for that task. Otherwise, the JSA may reference the SWP for that hazard.</p>	<p style="text-align: center;"><b>SWPs Applicable To This Project (check all applicable boxes)</b></p> <table style="width: 100%;"> <tr> <td><input checked="" type="checkbox"/> Hazard Communication</td> <td><input checked="" type="checkbox"/> Medical Services and First Aid</td> <td><input checked="" type="checkbox"/> Airborne Contaminants</td> <td><input type="checkbox"/> Heat Stress</td> </tr> <tr> <td><input type="checkbox"/> Cold Stress</td> <td><input checked="" type="checkbox"/> Natural Hazards</td> <td><input checked="" type="checkbox"/> Personal Protective Equipment</td> <td><input checked="" type="checkbox"/> Respiratory Protection</td> </tr> <tr> <td><input type="checkbox"/> Confined Space Entry</td> <td><input checked="" type="checkbox"/> Drum Handling</td> <td><input type="checkbox"/> Excavation</td> <td><input type="checkbox"/> Fall Protection and Prevention</td> </tr> <tr> <td><input type="checkbox"/> Forklift and Truck Operations</td> <td><input checked="" type="checkbox"/> Hand/Power Tool Use</td> <td><input checked="" type="checkbox"/> Heavy and Material Handling Equipment</td> <td><input type="checkbox"/> Ladder Safety</td> </tr> <tr> <td><input type="checkbox"/> Other Task (specify)</td> <td><input type="checkbox"/> Other Task (specify)</td> <td><input checked="" type="checkbox"/> Other Task (specify) <b>Traffic awareness/delineation</b></td> <td><input type="checkbox"/> Other Task (specify)</td> </tr> <tr> <td><input type="checkbox"/> Other Task (specify)</td> <td><input type="checkbox"/> Other Task (specify)</td> <td><input type="checkbox"/> Other Task (specify)</td> <td><input type="checkbox"/> Other Task (specify)</td> </tr> </table>	<input checked="" type="checkbox"/> Hazard Communication	<input checked="" type="checkbox"/> Medical Services and First Aid	<input checked="" type="checkbox"/> Airborne Contaminants	<input type="checkbox"/> Heat Stress	<input type="checkbox"/> Cold Stress	<input checked="" type="checkbox"/> Natural Hazards	<input checked="" type="checkbox"/> Personal Protective Equipment	<input checked="" type="checkbox"/> Respiratory Protection	<input type="checkbox"/> Confined Space Entry	<input checked="" type="checkbox"/> Drum Handling	<input type="checkbox"/> Excavation	<input type="checkbox"/> Fall Protection and Prevention	<input type="checkbox"/> Forklift and Truck Operations	<input checked="" type="checkbox"/> Hand/Power Tool Use	<input checked="" type="checkbox"/> Heavy and Material Handling Equipment	<input type="checkbox"/> Ladder Safety	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input checked="" type="checkbox"/> Other Task (specify) <b>Traffic awareness/delineation</b>	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)
<input checked="" type="checkbox"/> Hazard Communication	<input checked="" type="checkbox"/> Medical Services and First Aid	<input checked="" type="checkbox"/> Airborne Contaminants	<input type="checkbox"/> Heat Stress																						
<input type="checkbox"/> Cold Stress	<input checked="" type="checkbox"/> Natural Hazards	<input checked="" type="checkbox"/> Personal Protective Equipment	<input checked="" type="checkbox"/> Respiratory Protection																						
<input type="checkbox"/> Confined Space Entry	<input checked="" type="checkbox"/> Drum Handling	<input type="checkbox"/> Excavation	<input type="checkbox"/> Fall Protection and Prevention																						
<input type="checkbox"/> Forklift and Truck Operations	<input checked="" type="checkbox"/> Hand/Power Tool Use	<input checked="" type="checkbox"/> Heavy and Material Handling Equipment	<input type="checkbox"/> Ladder Safety																						
<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input checked="" type="checkbox"/> Other Task (specify) <b>Traffic awareness/delineation</b>	<input type="checkbox"/> Other Task (specify)																						
<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)	<input type="checkbox"/> Other Task (specify)																						

<p><b>Levels of Protection Required for each Task</b></p> <p>Signature of the SSO on page 1 of this document signifies certification of PPE Hazard Assessment</p>	<b>Task Description</b>	<b>Level</b>			
		A	B	C	D
	Supervision of well installations and borings.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
	Groundwater and soil sampling.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

<b>Personal Protective Equipment</b>  <b>Req=Required</b> <b>Rec=Recommended</b>  <b>An asterisk (*) indicates that employees must be a participant in the respiratory program, including, annual training and fit testing.</b>	Equipment	Req	Rec	NA	Equipment	Req	Rec	NA
	Steel Toe Boots	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Tyvek Suit	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Safety Glasses Shields	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Outer Disposable Boots	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Hi Vis Vest (Specify Class 2/3)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Indirect Vented Goggles	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Hi Vis Shirt	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Poly-Coated Tyvek	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Hard Hat	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Dust Mask*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Fire Resistant Clothing (FRC)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Full-Face Respirator*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Hearing Protection	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Half-Face Respirator*	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
	Work Gloves – Type: <a href="#">Nitrile</a>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Inner Chemical Gloves	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Outer Chemical Gloves	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<b>Training and Medical Surveillance</b>  <b>Req=Required</b> <b>Rec=Recommended</b>	Training	Req	Rec	NA	Medical Surveillance	Req	Rec	NA
	40 Hour HAZWOPER	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Medical Clearance (fit for duty)	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Current 8 Hour HAZWOPER	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Respirator Clearance	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	8 Hour HAZWOPER Supervisor	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Blood Lead and ZPP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	24Hour HAZWOPER	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Current CPR and First Aid	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	10 Hour Construction	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Other (specify)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<b>Safety Supplies</b>  <b>Req=Required</b> <b>Rec=Recommended</b>	Supplies	Req	Rec	NA	Supplies	Req	Rec	NA
	First Aid Kit	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Fire Extinguisher	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Eyewash Solution	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Water/Sports Drink	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
	Air Horn	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Oral Thermometer (heat monitoring)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Noise Meter (Dosimeter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Decontamination Supplies	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

<b>Work Zones</b>  If exclusion zones are necessary because of chemical OR equipment hazards, describe the plan	Exclusion Zone: The work area should be surrounded by multiple traffic cones so that the work area is highly visible to traffic. Portions of the work may be performed during nighttime hours. Work areas will be designated with cones, lights, vehicles with amber flashing beacons, and the drilling subcontractor will adhere a flag to the drill rig mast. Airside Ops will be notified of the contractors arrival and departure.		
	Additional exclusion zone requirements may be implemented based on correspondence with PDX Airside Operations Planner during portions of the field activities near or adjacent to runways or taxiways.		
	Contamination Reduction Zone:		
Support Zone:			

<b>Site Access/Control</b>  How do we limit unauthorized entry to the site itself?	Access Control Procedures: The facility is fenced and to enter you must pass through a guarded gate.		
<b>DECON Procedures</b>	Decontamination Procedures: Follow Level D PPE decontamination procedures.		

<b>Communication Plan</b>  In the event work must be completed alone by an Apex employee or work is performed in a rural area with limited communication, this Communication Plan must be completed.	The purpose of the communication plan is to provide a "What to Do" if the project manager/supervisor cannot contact field personnel. The field team and PM must coordinate a call in time daily. The check-in intervals will depend on the project setting and hazards. More importantly, if the field team does not check in, what is the requirement or actions of the PM.			
	Daily Check in Time	Responsible Person	Daily Check In Time	Responsible person
	1400	Chris Weer		
	Plan of Action (in the event of no communication): If no communication, project manager or safety officer will attempt to call responsible person or other on-site field staff. If no one is reachable, a message will be left and a second contact attempt will be made in 10 minutes. If no communication is made after 30 minutes, then the facility manager will be contacted directly. Alternatively, a representative from the Apex office may be sent to the terminal directly to communicate with field staff. The terminal is approximately a 40 minute drive from the Apex office.			

<b>Chemicals of Concern</b>  <b>In the section to the right, check any chemicals present onsite in any media (air, soil water).</b>  <b>In the table below, list chemicals suspected or confirmed to be onsite, and provide requested information.</b>	<input type="checkbox"/> Friable Asbestos <input type="checkbox"/> 3,3'-Dichlorobenzidine <input type="checkbox"/> Benzidine <input type="checkbox"/> beta-Propiolactone <input type="checkbox"/> N-Nitrosomethylamine <input type="checkbox"/> Lead <input checked="" type="checkbox"/> Benzene <input type="checkbox"/> Acrylonitrile <input type="checkbox"/> Methylenedianiline <input checked="" type="checkbox"/> Other _____	<input type="checkbox"/> alpha-Naphthylamine <input type="checkbox"/> bis-Chloromethyl ether <input type="checkbox"/> 4-Aminodiphenyl <input type="checkbox"/> 2-Acetylaminoflourene <input type="checkbox"/> Vinyl chloride <input type="checkbox"/> Chromium (VI) <input type="checkbox"/> Coke oven emissions <input type="checkbox"/> Ethylene oxide <input type="checkbox"/> 1,3-Butadiene <input checked="" type="checkbox"/> <b>No Apex exposure to these</b>	<input type="checkbox"/> Methyl chromoethyl ether <input type="checkbox"/> beta-Naphthylamine <input type="checkbox"/> Ethyleneimine <input type="checkbox"/> 4-Dimethylaminoazobenzene <input type="checkbox"/> Inorganic arsenic <input type="checkbox"/> Cadmium <input type="checkbox"/> 1,2-Dibromo-3-chloropropane <input type="checkbox"/> Formaldehyde <input type="checkbox"/> Methylene chloride <input checked="" type="checkbox"/> Sub Slab VOCs
--	--	---	---

Materials Present or Suspected at Site	Highest Reported Concentration (specify units and sample medium)	Exposure Limit (specify ppm or mg/m <sup>3</sup> )	IDLH Level (specify ppm or mg/m <sup>3</sup> )	Primary Hazards of the Material (explosive, flammable, corrosive, toxic, volatile, radioactive, biohazard, oxidizer, or other)	Symptoms and Effects of Acute Exposure	Ionization Potential (eV)
Petroleum Hydrocarbons		PEL = 500 REL = 350 TLV = Skin Hazard <input type="checkbox"/>	1,100ppm	Flammable	Fatigue, headache, nausea, dizziness. Exposure to high levels can lead to coma or death.	
Benzene		PEL = 1 ppm REL = 0.1 ppm TLV = Skin Hazard <input type="checkbox"/>	500 ppm	Flammable	Drowsiness, dizziness, rapid heart rate, headache, tremors, confusion, and unconsciousness. Exposure to very high levels can lead to death.	
PCB's		PEL = 0.5 mg/m <sup>3</sup> REL = TLV = Skin Hazard <input type="checkbox"/>	5 mg/m <sup>3</sup>	Strong oxidizers	irritation eyes, chloracne; liver damage; reproductive effects; [potential occupational carcinogen	
Toluene		PEL = 200 ppm REL = 100 ppm TLV = Skin Hazard <input type="checkbox"/>	500 ppm	Flammable	Causes mild to moderate skin irritation. Inhalation or ingestion may cause nausea, headache, dizziness, tremors, restlessness, lightheadedness, exhilaration, memory loss, insomnia, impaired reaction time, drowsiness	

PEL = OSHA Permissible Exposure Limit  
 REL = NIOSH Recommended Exposure Limit  
 TLV = ACGIH Threshold Limit Value  
 IDLH = Immediately Dangerous to Life or Health




Monitoring Equipment: All monitoring equipment on site must be calibrated before and after each use and results recorded.				
Instrument (Check all required)	Task	Instrument Reading	Action Guideline	Comments
<input type="checkbox"/> Combustible gas indicator model:	<input type="checkbox"/> 1	0 to 10% LEL	Monitor; evacuate if confined space	
	<input type="checkbox"/> 2	10 to 25% LEL	Potential explosion hazard	
	<input type="checkbox"/> 3			
	<input type="checkbox"/> 4	>25% LEL	Explosion hazard; interrupt task; evacuate site	
	<input type="checkbox"/> 5			
<input type="checkbox"/> Oxygen meter model:	<input type="checkbox"/> 1	>23.5% Oxygen	Potential fire hazard; evacuate site	
	<input type="checkbox"/> 2	23.5 to 19.5% Oxygen	Oxygen level normal	
	<input type="checkbox"/> 3			
	<input type="checkbox"/> 4	<19.5% Oxygen	Oxygen deficiency; interrupt task; evacuate site	
	<input type="checkbox"/> 5			
<input type="checkbox"/> Radiation survey meter model:	<input type="checkbox"/> 1	Normal background	Proceed	Annual exposure not to exceed 1,250 mrem per quarter Background reading must be taken in an area known to be free of radiation sources
	<input type="checkbox"/> 2			
	<input type="checkbox"/> 3	Two to three times background	Notify SSO	
	<input type="checkbox"/> 4	>Three times background	Radiological hazard; interrupt task; evacuate site	
	<input type="checkbox"/> 5			
<input type="checkbox"/> Photoionization detector model: <input type="checkbox"/> 11.7 eV <input checked="" type="checkbox"/> 10.6 eV <input type="checkbox"/> 10.2 eV <input type="checkbox"/> 9.8 eV  <input type="checkbox"/> ____ eV	<input type="checkbox"/> 1	Any response above background to 5 ppm above background	Level D is acceptable	Action levels must be determined based on the COCs and concentrations identified in the media sampled. If no COC concentrations are known, then use 5 ppm sustained within the breathing zone as your action level until the contaminants are identified.
	<input type="checkbox"/> 2			
	<input type="checkbox"/> 3	ppm above background	Level C (not anticipated)	
	<input type="checkbox"/> 4			
	<input type="checkbox"/> 5	ppm above background	Discontinue work	
<input type="checkbox"/> Flame ionization detector model:	<input type="checkbox"/> 1	Any response above background to ____ ppm above background	Level C is acceptable Level B is recommended	Action levels must be determined based on the COCs and concentrations identified in the media sampled. If no COC concentrations are known, then use 5 ppm sustained within the breathing zone as your action level until the contaminants are identified.
	<input type="checkbox"/> 2	____ ppm above background	Level B	
	<input type="checkbox"/> 3			
	<input type="checkbox"/> 4	above background	Level A	
	<input type="checkbox"/> 5			
<input type="checkbox"/> Detector tube models:	<input type="checkbox"/> 1	Specify:	Specify:	The action level for upgrading the level of protection is one-half of the contaminant's PEL. If the PEL is reached, evacuate the site and notify a safety specialist.
	<input type="checkbox"/> 2			
	<input type="checkbox"/> 3			
	<input type="checkbox"/> 4			
	<input type="checkbox"/> 5			
<input type="checkbox"/> Other (specify):	<input type="checkbox"/> 1	Specify:	Specify:	
	<input type="checkbox"/> 2			
	<input type="checkbox"/> 3			
	<input type="checkbox"/> 4			
	<input type="checkbox"/> 5			

<p><b>Emergency Response Planning</b></p> <p><b>In the pre-work briefing and Daily Tailgate Safety meetings, all onsite employees will be trained in the provisions of emergency response planning, site communication systems, and site evacuation routes.</b></p> <p><b>Signal a site emergency or medical emergency with three blasts of a loud horn (car horn, fog horn, or similar device).</b></p> <p><b>To complete this section, attach a hospital route map to the HASP.</b></p>	<p><b>All work-related incidents must be reported. For all medical emergencies, call 911 or the local emergency number. For non-emergency incidents, you must:</b></p> <ul style="list-style-type: none"> <li>• Give appropriate first aid care to the injured or ill individual and secure the scene.</li> <li>• Immediately call WorkCare at (888) 449-7787 (available 24 hours/7 days per week) if the injured person is an Apex employee.</li> <li>• Notify the Project Manager and/or SSO after calling WorkCare.</li> <li>• Enter the safety incident into the Apex Incident Report and submit to <a href="mailto:incidents@apexcoss.com">incidents@apexcoss.com</a> within 24 hours.</li> </ul> <p><b>In the event of an emergency that necessitates evacuation of the work task area or the site as a whole, the following procedures shall occur:</b></p> <ul style="list-style-type: none"> <li>• The Apex site supervisor or Project Manager will contact all nearby personnel using the onsite communications system to advise of the emergency.</li> <li>• Personnel will proceed along site roads to a safe distance upwind from the hazard source to a pre-determined assembly area.</li> <li>• Call 911</li> <li>• Personnel will remain in that area until the site supervisor or Project Manager or other authorized individual provides further instruction.</li> </ul> <p><b>In the event of a severe spill or leak, site personnel will follow the procedures listed below:</b></p> <ul style="list-style-type: none"> <li>• Evacuate the affected area and relocate personnel to an upwind, pre-determined assembly area.</li> <li>• Inform the Apex site supervisor or Project Manager, an Apex office, and a site representative immediately.</li> <li>• Locate the source of the spill or leak and stop the source if it is safe to do so until appropriately trained personnel are onsite to do so.</li> <li>• Begin containment and recovery of spilled or leaked materials.</li> <li>• Notify appropriate local, state, and federal agencies after obtaining client consent to do so.</li> </ul> <p><b>In the event of severe weather, site personnel will follow the procedures listed below:</b></p> <ul style="list-style-type: none"> <li>• Site work shall not be conducted during severe weather, including high winds and lightning.</li> <li>• In the event of severe weather, stop work, lower any equipment (drill rigs), and evacuate the affected area.</li> <li>• Monitor internet or other sources for severe weather alerts before resuming work.</li> <li>• In the event of lightning, outdoor work must be halted for a minimum of 30 minutes from the last lightning observation.</li> </ul>
---	--

Emergency Contacts	Name	Location	Phone	Cell Phone
Hospital (attach map)	Providence Portland Medical Center	4805 NE Glisan St. Portland, OR	503-215-5526	
Police	911		911	
Fire	911		911	
Project Manager	Carmen Owens	Portland, OR	503-924-4704	319-360-4128
Field Manager (if not PM)	Chris Weer	Portland, OR	503-924-4704	971-806-1637
Site Safety Officer (if not PM)	Chris Weer		503-924-4704	
Division H&S Contact	Lauren Bellinger	Portland, OR	503-924-4704	
Corporate H&S Contact	Josh House	Rockville, MD	301-417-0200	
Incident Intervention	WorkCare	NA	888-449-7787	
Subcontractor Safety Contact				
Subcontractor Safety Contact				





Vibra  
Specialty  
Hospital of  
Portland  
  
VA East  
Portland Clinic



## Groundwater Sampling Job Safety Analysis (JSA)

Project Number:	32-24009923	Project/Client Name:	Port of Portland		
Project Manager:	Carmen Owens	Project Location:	PDX		
Specific Task:	Collect samples from monitoring wells				
Minimum Required PPE for Task:	<input checked="" type="checkbox"/> Hard Hat <input checked="" type="checkbox"/> Hearing Protection <input type="checkbox"/> Hi-Vis Shirt <input type="checkbox"/> Coverall <input type="checkbox"/> Face Shield <input type="checkbox"/> Other (specify): <input checked="" type="checkbox"/> Safety Toed Boots <input type="checkbox"/> Long Sleeved Shirt <input checked="" type="checkbox"/> Hi-Vis Vests Class 2 <input checked="" type="checkbox"/> Gloves <input type="checkbox"/> Respirator <input type="checkbox"/> <type>      <enter additional PPE here> <input checked="" type="checkbox"/> Safety Glasses <input type="checkbox"/> Fire Resistant Clothing <input type="checkbox"/> Hi-Vis Vests Class 3 <input type="checkbox"/> <type and cartridge>				
Additional Task-Step Specific PPE: (as indicated below under controls)	NA	Equipment/Tools Required:	Peristaltic pump, hand tools		
Training Required for this Task:	HAZWOPER40	Permits Required for this Task: (e.g. confined space, LOTO)	NA		
Forms Associated with this Task:	HASP, Daily Tailgate Meeting form, monitoring and gauging forms.				
JSA Developed/Reviewed By:			Date and Revision Number: 6/19/2024		
Employee Name/Job Title	Employee Name/Job Title	Employee Name/Job Title	H&S Team Leader to ensure all personnel performing this task have reviewed JSA and agree to follow it. Site specific changes to this JSA have been made as warranted based on this review. <u>H&amp;S Team Leader Signature/Date:</u>		
Carmen Owens					
Task Steps	Potential Hazards and Consequences	Likelihood	Severity	Risk	Controls to Eliminated/Reduce Risks
1. Pre-Field Safety Meeting	N/A			0	All employees will attend a pre-field meeting which will include the pertinent SOPs, client-specific Job Safety Analysis, Permit(s) to Work (if required), Subsurface Investigation Procedures, potential hazards, and actual hazards present and controls for those hazards
2. Travelling to/from the Site	2a. Traffic accident - Injury	3	3	9	Follow posted speed limits and traffic signs. Stay alert to to other vehicles, cyclists, pedestrians and be a defensive driver by maintaining a safe distance with other vehicles on the road.
	2b. Improperly secured load - Accident or injury	2	3	6	Maintain good housekeeping to securely load vehicles and ensure that loose or light items that may shift during travel are secured. Use ratcheting straps, covers, etc to secure loads.
3. Loading and Unloading Equipment	3a. Moving equipment - back or muscle strain	2	3	6	Ensure proper lifing techniques. Do not attempt to bodily move large equipment. Use the buddy lift to move heavy objects.
	3b. Slip/trips/falls - Injury	2	3	6	Maintain good housekeeping. Inspect the area of tripping hazards. If grass or vegetation is tall, objects may be obscured. Ensure good footing in the work area. Sturdy work boot required
4. Calibration of equipment	Skin or eye contact with calibration chemicals	2	2	4	Wear disposable gloves and safety glasses, avoid direct contact with calibration solutions. Properly dispose of calibration solution waste.

**Groundwater Sampling  
Job Safety Analysis (JSA)**

Project Number:	32-24009923	Project/Client Name:		Port of Portland	
Project Manager:	Carmen Owens	Project Location:		PDX	
Specific Task:	Collect samples from monitoring wells				
Task Steps	Potential Hazards and Consequences	Likelihood	Severity	Risk	Controls to Eliminated/Reduce Risks
5. Setup and installation of low-flow pump	5a. Potential hand injuries during pump setup.	2	2	4	Wear gloves when preparing pump and equipment for sampling
	5b. Traffic consideration - Injury	3	3	9	Some well are located adjacent to roadways in the right-of-way. Maintain a well delineated work area using cones, field vehicle, or other barricades to avoid hazards from vehicular traffic.
	5c. Slip/trips/falls - Injury	2	3	6	Maintain good housekeeping. Inspect the area of tripping hazards. If grass or vegetation is tall, objects may be obscured. Ensure good footing in the work area. Sturdy work boot required
	5d. Lifting or moving equipment - Injury	2	3	6	Ensure proper lifing techniques. Do not attempt to bodily move large equipment. Use the buddy lift to move heavy objects.
	5e. Unexpected release of pressure from compressor - Injury	2	2	4	Check compressor and air plines for damage to avoid unexpected pressure release. Maintain recommended pressure.
6. Sample Collection	6a. Contact with potentially contaminated groundwater - Exposure	2	2	4	Wear disposable goves and safety glasses when collecting samples to minimize contact with contaminated media.
	6b. Contact with acids from sample preservation.	2	2	4	Wear disposable gloves and safety glasses or goggles when handling acids. Quantites handled are generally very small, so large spills are unlikely. In the event of contact with acid, wash area thoroughly with fresh water.
	6c. Slip/trips/falls - Injury	2	3	6	Maintain good housekeeping. Inspect the area of tripping hazards. Sturdy work boot required. Maintain 3-points of contact when using stairways.
	6d. Sample mangement - Injury from damaged glassware	2	2	4	Inspect bottles before use. Wear gloves and use care when handling glass sampling containers to avoid hand lacerations.
	6e. Moving equipment or full sample coolers - Back or muscle injury.	2	3	6	Ensure proper lifing techniques. Do not attempt to bodily move large equipment. Use the buddy lift to move heavy coolers.
	6f. Cutting or Disconnecting sample tubing - Hand injury	2	3	6	Wear leather gloves (or similar) when using cutting tools to cut and/or disconnect tubing.
7. Cleanup and movement between sample locations.	7a. Visitor mishaps resulting in bodily harm.	3	3	9	Pay attention to visitors approaching work area. When necessary, setup traffic cones and/or other traffic barriers to keep vehicles and visitors out of the work area. Use caution tape if available

**Groundwater Sampling  
Job Safety Analysis (JSA)**

Project Number:	32-24009923	Project/Client Name:	Port of Portland		
Project Manager:	Carmen Owens	Project Location:	PDX		
Specific Task:	Collect samples from monitoring wells				
Task Steps	Potential Hazards and Consequences	Likelihood	Severity	Risk	Controls to Eliminated/Reduce Risks
	7b. Tripping over equipment as it is taken apart and laying on ground before being loaded.	3	2	6	All personnel should be constantly watching for trip hazards such as uneven terrain, holes, ditches, stretched wires or ropes, or any other materials or pieces of equipment in their path
	7c. Hurting back trying to lift heavy objects.	3	3	9	Use proper lifting techniques to avoid back strain. Get help if the object is too heavy by yourself.
8. Management of Investigation Derived Waste	8a. Slip/trips/falls - Injury	2	3	6	Maintain good housekeeping. Inspect the area of tripping hazards. Sturdy work boot required. Maintain 3-points of contact when using stairways.
	8b. Potential hand injuries while opening/closing accumulation drum	2	3	6	Wear leather (or similar) work gloves and hand tools when opening and closing the lids to accumulation storage drums to avoid pinching hand in the ring or cutting hand on the drum or lid..
	8c. Spill - Environmental impact	2	2	4	Have absorbant pads and/or rags available in the event of a spill. Wear gloves when handling pads or potentially contaminated material.
9. Site wide Activities	9a. Slip/trips/falls - Injury	2	3	6	Maintain good housekeeping. Inspect the area of tripping hazards. Sturdy work boot required. Maintain 3-points of contact when using stairways.
	9b. Traffic considerations - Injury	2	3	6	Some wells are located in active traffic areas for terminal operation. Maintain a well delineated work area using cones, field vehicle, or other barricades to avoid hazards from vehicular traffic.

			Hazard Severity				
			1	2	3	4	5
			<b>INSIGNIFICANT</b> negligible or no injury could result	<b>MINOR</b> minor injury requiring only first aid	<b>MODERATE</b> injury resulting in lost time could occure	<b>HIGH</b> serious injury or death could occur	<b>VERY HIGH</b> multiple deaths could occur
Likelihood	1	VERY UNLIKELY	1	2	3	4	5
	2	UNLIKELY	2	4	6	8	10
	3	POSSIBLE	3	6	9	12	15
	4	LIKELY	4	8	12	16	20
	5	VERY LIKELY	5	10	15	20	25



## Drill Rig Well Installation Job Safety Analysis (JSA)

Project Number:	32-24009923	Project/Client Name:	Fire Stations Characterization/Port of Portland		
Project Manager:	Carmen Owens	Project Location:	Portland, OR		
Specific Task:	Oversee Soil Borings and Well Installation				
Minimum Required PPE for Task:	<input checked="" type="checkbox"/> Hard Hat <input checked="" type="checkbox"/> Hearing Protection <input type="checkbox"/> Hi-Vis Shirt <input type="checkbox"/> Coverall <input type="checkbox"/> Face Shield <input type="checkbox"/> Other (specify): <input checked="" type="checkbox"/> Safety Toed Boots <input type="checkbox"/> Long Sleeved Shirt <input checked="" type="checkbox"/> Hi-Vis Vests Class 2 <input checked="" type="checkbox"/> Gloves    Nitril <input checked="" type="checkbox"/> Safety Glasses <input type="checkbox"/> Fire Resistant Clothing <input type="checkbox"/> Hi-Vis Vests Class 3 <input type="checkbox"/> Respirator				
Additional Task-Step Specific PPE: (as indicated below under controls)	NA	Equipment/Tools Required:	Oversight of drill rig		
Training Required for this Task:	HAZWOPER40	Permits Required for this Task: (e.g. confined space, LOTO)			
Forms Associated with this Task:	HASP, Daily Tailgate Meeting form, field logs				
JSA Developed/Reviewed By:			Date and Revision Number:	4/15/2023	
Employee Name/Job Title	Employee Name/Job Title	Employee Name/Job Title	H&S Team Leader to ensure all personnel performing this task have reviewed JSA and agree to follow it. Site specific changes to this JSA have been made as warranted based on this review. <u>H&amp;S Team Leader Signature/Date:</u>		
Carmen Owens/PM					
Task Steps	Potential Hazards and Consequences	Likelihood	Severity	Risk	Controls to Eliminated/Reduce Risks
1. Pre-Field Safety Meeting	N/A			0	All employees will attend a pre-field meeting which will include the pertinent SOPs, client-specific Job Safety Analysis, Permit(s) to Work (if required), Subsurface Investigation Procedures, potential hazards, and actual hazards present and controls for those hazards
2. Site Setup and Mobilization	2a. Striking underground lines or objects with drill.	3	2	6	The one-call notification system should be called 2 days before commencing any drilling activities. Observe surrounding before starting to drill. Private Locate onsite before drilling to begin.
	2b. Vehicle traffic - striking/hitting workers	3	3	9	Setup traffic safety perimeter with traffic cones to delineate work area - use caution tape if available. Keep a watchful eye on traffic when moving outside of delineated work area. Wear high visibility PPE.
3. Drilling Activities	3a. Noise related injuries.	3	2	6	Wear approved safety ear plugs when working in the vicinity of the drill rig.

**Drill Rig Well Installation**  
**Job Safety Analysis (JSA)**

Project Number:	32-24009923	Project/Client Name:		Fire Stations Characterization/Port of Portland	
Project Manager:	Carmen Owens	Project Location:		Portland, OR	
Specific Task:	Oversee Soil Borings and Well Installation				
3. Drilling Activities (continued)	3b. Physical injuries from moving parts of machinery.	3	3	9	Avoid moving parts in the machinery. Keep fingers, hands, and arms away from the rotating drill head near the top or near the bottom. Keep fingers away from pinch points when screwing pipe joints together. Wear leather gloves when handling objects and wear hard hat and steel-toed boots at all times.
	3c. Exposure to contaminated media	3	2	6	Monitor the air space of each drill location before, during, and after drilling with a photoionization detector for VOCs and follow the site-specific Health and Safety Plan
	3d. Physical hazards to personnel in the vicinity of machinery.	3	3	9	Personnel should keep away from the drill unless they are required for the task. Drillers should be aware of people in area. Do not approach driller without first establishing eye contact with the operator.
	3e. Physical injury from drill.	3	3	9	Stand clear as drill is moving. Wear gloves and hard hat.
	3f. Oxygen depletion from indoor use of equipment	3	3	9	Drilling company will use engineering controls (vent to outdoors) to mitigate. Apex will monitor CO with meter. OSHA PEL is 50 ppm, our action level will be 20 ppm based on literature information that suggest manual dexterity is affected at 35 ppm.
	3g. Injury during moving of drill	3	2	6	Be aware of water and equipment on the ground when moving.
4. Cleanup and movement of the drill locations.	4a. Visitor mishaps resulting in bodily harm.	3	3	9	Pay attention to visitors approaching work area. When necessary, setup traffic cones and/or other traffic barriers to keep vehicles and visitors out of the work area. Use caution tape if available
	4b. Striking overhead lines or objects with drill.	3	2	6	Observe for overhead lines or other objects during movement of drill rig.
	4c. Tripping over equipment as it is taken apart and laying on ground before being loaded.	3	2	6	All personnel should be constantly watching for trip hazards such as uneven terrain, holes, ditches, stretched wires or ropes, or any other materials or pieces of equipment in their path
	4d. Hurting back trying to lift heavy objects.	3	3	9	Use proper lifting techniques to avoid back strain. Get help if the object is too heavy by yourself.

			Hazard Severity				
			1	2	3	4	5
			<b>INSIGNIFICANT</b> negligible or no injury could result	<b>MINOR</b> minor injury requiring only first aid	<b>MODERATE</b> injury resulting in lost time could occure	<b>HIGH</b> serious injury or death could occur	<b>VERY HIGH</b> multiple deaths could occur
Likelihood	1	VERY UNLIKELY	1	2	3	4	5
	2	UNLIKELY	2	4	6	8	10
	3	POSSIBLE	3	6	9	12	15
	4	LIKELY	4	8	12	16	20
	5	VERY LIKELY	5	10	15	20	25



**Airside Construction**  
**Job Safety Analysis (JSA)**

Project Number:	32-24009923	Project/Client Name:	Port of Portland		
Project Manager:	Carmen Owens	Project Location:	PDX		
Specific Task:	Arrival at PDX and travel and setup for drilling.				
Minimum Required PPE for Task:	<input checked="" type="checkbox"/> Hard Hat <input checked="" type="checkbox"/> Hearing Protection <input type="checkbox"/> Hi-Vis Shirt <input type="checkbox"/> Coverall <input type="checkbox"/> Face Shield <input type="checkbox"/> Other (specify): <input checked="" type="checkbox"/> Safety Toed Boots <input type="checkbox"/> Long Sleeved Shirt <input checked="" type="checkbox"/> Hi-Vis Vests Class 2 <input checked="" type="checkbox"/> Gloves      <type>      <enter additional PPE here> <input checked="" type="checkbox"/> Safety Glasses <input type="checkbox"/> Fire Resistant Clothing <input type="checkbox"/> Hi-Vis Vests Class 3 <input checked="" type="checkbox"/> Respirator      <type and cartridge>				
Additional Task-Step Specific PPE: (as indicated below under controls)	NA	Equipment/Tools Required:	Drill rig		
Training Required for this Task:	HAZWOPER40, Port security badge	Permits Required for this Task: (e.g. confined space, LOTO)	NA		
Forms Associated with this Task:	HASP, Daily Tailgate Meeting form, field log, lithologic log, and sampling sheets				
JSA Developed/Reviewed By:			Date and Revision Number: 6/19/2024		
Employee Name/Job Title	Employee Name/Job Title	Employee Name/Job Title	H&S Team Leader to ensure all personnel performing this task have reviewed JSA and agree to follow it. Site specific changes to this JSA have been made as warranted based on this review. <u>H&amp;S Team Leader Signature/Date:</u>		
Carmen Owens					
Task Steps	Potential Hazards and Consequences	Likelihood	Severity	Risk	Controls to Eliminated/Reduce Risks
1. Pre-Field Safety Meeting	N/A				All employees will attend a pre-field meeting which will include the pertinent SOPs, client-specific Job Safety Analysis, Permit(s) to Work (if required), Subsurface Investigation Procedures, potential hazards, and actual hazards present and controls for those hazards.
2. Arrival at gate of Airfield.	Dangerous to travel to site, planes or other heavy traffic.	1	4	4	Call Operations at gate to inform of arrival and make sure it is clear to travel to sample locations.
3. Travel to work area.	Plane traffic and other vehicle traffic in the area.	1	4	4	Use route that has been determined as safest, stay on roadway and use flashers on vehicle when on airfield. Obey posted speed limits. Make sure drill crew is escorted to site. Follow Port rules.
4. Set up work area	4a. Not being visible to planes and other vehicles .	2	4	8	Use cones and signage to delineate the work area and that operations knows where you are going to be located.

**Airside Construction**  
**Job Safety Analysis (JSA)**

Project Number:	32-24009923	Project/Client Name:	Port of Portland		
Project Manager:	Carmen Owens	Project Location:	PDX		
Specific Task:	Arrival at PDX and travel and setup for drilling.				
Task Steps	Potential Hazards and Consequences	Likelihood	Severity	Risk	Controls to Eliminated/Reduce Risks
	4b. Drill mast not being visible to low flying aircraft.	2	4	8	Secure all material inside of vehicles, be aware of FOD (Foreign Object Debris). Practice good houskeeping.
	4c. Working at night near runway, not being visible.	2	4	8	Set up lights to see and be seen, work with Airport OPS for permission when we can mobilize to location.
5. Perform work at site	Material not secured and blowing around could get sucked into aircraft engines.	1	4	4	Secure all material inside of vehicles, be aware of FOD (Foreign Object Debris). Practice good houskeeping.
6. Clean up site	6a. Material left behind and blowing onto runway. Debris on tires.	1	4	4	Check work area to make sure nothing is left behind. Check tires for FOD. Use GOAL (Get out and look). Call Operations to check if site inspection is required and let them know you aretravelling to the gate. Practice good housekeeping.
7. Travel from work area.	Plane traffic and other vehicle traffic in the area.	1	4		Use route that has been determined as safest, stay on roadway and use flashers on vehicle when on airfield. Obey posted speed limits. Make sure drill crew is escorted from site. Follow Port rules.
8. Arrival at gate of Airfield.	N/A				Call Operations at gate to inform of departure of airfield.

			Hazard Severity				
			1	2	3	4	5
			<b>INSIGNIFICANT</b> negligible or no injury could result	<b>MINOR</b> minor injury requiring only first aid	<b>MODERATE</b> injury resulting in lost time could occure	<b>HIGH</b> serious injury or death could occur	<b>VERY HIGH</b> multiple deaths could occur
Likelihood	1	VERY UNLIKELY	1	2	3	4	5
	2	UNLIKELY	2	4	6	8	10
	3	POSSIBLE	3	6	9	12	15
	4	LIKELY	4	8	12	16	20
	5	VERY LIKELY	5	10	15	20	25